

Neousys Technology Inc.

Nuvo-9160GC Series

User Manual

Revision 1.1

Table of Contents

Table of Contents	2
Legal Information	5
Contact Information	
Declaration of Conformity	
Copyright Notice	
Safety Precautions	
Service and Maintenance	
Avertissement concernant les piles	
Hot Surface Warning	
Surface chaude	
Battery Warning	
Entretien et ecessarie	
ESD Precautions	
Précautions ecessaries de décharge électrostatique (ESD)	
Restricted Access Location	
Lieu d'accès restreint	
About This Manual	

1 Introduction

1.1	Product Specifications	17
1.1.1	Nuvo-9160GC Specifications	17
1.1.2	Nuvo-9166GC Specification	
1.2	Nuvo-9160GC Dimension	22
1.2.1	Nuvo-9160GC Front Panel View	22
1.2.2	Nuvo-9160GC Rear Panel View	
1.2.3	Nuvo-9160GC Side View	23
1.2.4	Nuvo-9160GC Top View	23
1.2.5	Nuvo-9160GC Bottom View	24
1.3	Nuvo-9166GC Dimension	25
1.3.1	Nuvo-9166GC Front Panel View	25
1.3.2	Nuvo-9166GC Rear Panel View	25
1.3.3	Nuvo-9166GC Side View	
1.3.4	Nuvo-9166GC Top View	
1.3.5	Nuvo-9166GC Bottom View	

2 System Overview

2.1	Packing List	
2.1.1	Nuvo-9160GC Series Packing List	28
2.1.2	Nuvo-9166GC Series Packing List	29
2.2	Front Panel I/O	30
2.2.1	USB3.2 Gen2x1 Port	
2.2.2	USB2.0 Port	32
2.2.3	CMOS Reset Button	33
2.2.4	DVI Port	34
2.2.5	VGA Port	35
2.2.6	USB3.2 Gen 1x1 Port	36
2.2.7	DisplayPort	37
2.2.8	USB3.2 Gen2x2 Type-C Port	38
2.2.9	2.5 Ethernet Port/ Optional PoE+	39
2.2.10		
2.2.11	LED Indicators	40
2.2.12	Power Button	41
2.2.13	Cassette Module	42
2.3	Rear Panel I/O	
2.3.1	4-Pole 3.5mm Headphone/ Microphone Jack	45
2.3.2	COM Ports	46
2.3.3	3-Pin Terminal Block for DC and Ignition Input	47

2.3.4	3-Pin Remote On/ Off	48
2.4	Internal I/O Functions	49
2.4.1	Dual SODIMM DRAM Slot	49
2.4.2	mini-PCIe Socket & Pin Definition	50
2.4.3	M.2 2242/ 3042/ 3052 (B Key), Mini-SIM Card Slot & Pin Definition	52
2.4.4	SATA Ports	54
2.4.5	DIP Switch	55
2.4.6	On/ Off Ctrl & Status Output	56
2.4.7	Internal USB 2.0 Port	57
2.4.8	M.2 2280 (M Key) Slot for NVMe SSD	
2.4.9	MezIO [™] Interface & Pin Definition	

3 System Installation

3.1	Disassembling the System	.63
3.2	Installing Internal Components	.67
3.2.1	CPU Installation for Barebone System	. 67
3.2.2	Remove and Replace the Existing CPU	.73
3.2.3	DDR5 SO-DIMM Installation	. 80
3.2.4	mPCIe Module, Mini-SIM (2FF) Card and Antenna Installation	.82
3.2.5	M.2 2242/ 3042/ 3052 (B Key) Module and Micro-SIM (3FF) Card Installation	
3.2.6	M.2 2280 NVMe SSD Installation	.86
3.2.7	MezIO [™] Module Installation	. 88
3.2.8	HDD/ SSD Installation	
3.2.9	Ethernet/ PoE+ Port Panel Screw Fix	. 94
3.3	Nuvo-9160GC Graphics Card Replacement/ Installation	.95
3.4	Nuvo-9166GC Series Graphics Card Replacement/ Installation	103
3.5	Installing the System Enclosure	109
3.6	Wall Mount Bracket Installation	112
3.6.1	Wall Mount Bracket Installation	
3.6.2	Damping Bracket Installation (Optional)	114
3.7	Powering On the System	115
3.7.1	Powering On Using the Power Button	
3.7.2	Powering On Using External Non-latched Switch	116
3.7.3	Powering On Using Wake-on-LAN	117

4 System Configuration

BIOS	Settings	119
	COM Port Configuration	120
	COM Port High Speed Mode	
	Delay for PEG Initialization	122
	Volume Management Device (VMD)	123
	TPM Availability	126
	Auto Wake on S5	129
	Power On After Power Failure Option	
	Power & Performance (CPU SKU Power Configuration)	131
	Wake on LAN Option	
	Boot Menu	133
	Add Boot Options (Position New Boot Device)	135
AMT		
RAID	Configuration	139
	Enabling Volume Management Device (VMD) for RAID Volume Setup	139
	RAID Volume Setup	141
	Loading RAID Driver for Windows Installation	
	АМТ	COM Port Configuration COM Port High Speed Mode Delay for PEG Initialization Volume Management Device (VMD) TPM Availability Power over Ethernet (PoE) Power Enable Auto Wake on S5 Power On After Power Failure Option Power & Performance (CPU SKU Power Configuration) Wake on LAN Option Boot Menu Add Boot Options (Position New Boot Device) Watchdog Timer for Booting AMT Configuration RAID Configuration Enabling Volume Management Device (VMD) for RAID Volume Setup RAID Volume Setup

5 OS Support and Driver Installation

5.1	Operating System Compatibility	151
	System Driver Installation	
5.3	Driver Installation for Watchdog Timer Control	152

Appendix A Using WDT & DIO

/DT and DIO Library Installation1	154
DT Functions	
itWDT1	
etWDT1	
tartWDT1	
esetWDT1	157
topWDT1	157

Appendix B PoE On/ Off Control

GetStatusPoEPort	158
EnablePoEPort	159
DisablePoEPort	160

Legal Information

All Neousys Technology Inc. products shall be subject to the latest Standard Warranty Policy

Neousys Technology Inc. may modify, update or upgrade the software, firmware or any accompanying user documentation without any prior notice. Neousys Technology Inc. will provide access to these new software, firmware or documentation releases from download sections of our website or through our service partners.

Before installing any software, applications or components provided by a third party, customer should ensure that they are compatible and interoperable with Neousys Technology Inc. product by checking in advance with Neousys Technology Inc.. Customer is solely responsible for ensuring the compatibility and interoperability of the third party's products. Customer is further solely responsible for ensuring its systems, software, and data are adequately backed up as a precaution against possible failures, alternation, or loss.

For questions in regards to hardware/ software compatibility, customers should contact Neousys Technology Inc. sales representative or technical support.

To the extent permitted by applicable laws, Neousys Technology Inc. shall NOT be responsible for any interoperability or compatibility issues that may arise when (1) products, software, or options not certified and supported; (2) configurations not certified and supported are used; (3) parts intended for one system is installed in another system of different make or model.

Contact Information

Headquarters (Taipei, Taiwan)	Neousys Technology Inc. 15F, No.868-3, Zhongzheng Rd., Zhonghe Dist., New Taipei City, 23586, Taiwan Tel: +886-2-2223-6182 Fax: +886-2-2223-6183 <u>Email</u> , <u>Website</u>
Americas (Illinois, USA)	Neousys Technology America Inc. 3384 Commercial Avenue, Northbrook, IL 60062, USA Tel: +1-847-656-3298 <u>Email</u> , <u>Website</u>
China	Neousys Technology (China) Ltd. Room 612, Building 32, Guiping Road 680, Shanghai Tel: +86-2161155366 <u>Email, Website</u>

Declaration of Conformity

FCC

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at own expense.

CE

The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

Copyright Notice

All rights reserved. This publication may not be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written consent of Neousys Technology, Inc.

- Disclaimer This manual is intended to be used as an informative guide only and is subject to change without prior notice. It does not represent commitment from Neousys Technology Inc. Neousys Technology Inc. shall not be liable for any direct, indirect, special, incidental, or consequential damages arising from the use of the product or documentation, nor for any infringement on third party rights.
- Patents andNeousys, the Neousys logo, Expansion Cassette, MezIO[™] are registeredTrademarkspatents and trademarks of Neousys Technology, Inc.

Windows is a registered trademark of Microsoft Corporation.

Intel[®], Core[™] are registered trademarks of Intel Corporation

NVIDIA® is a registered trademark of NVIDIA Corporation

All other names, brands, products or services are trademarks or registered trademarks of their respective owners.

Safety Precautions

- Read these instructions carefully before you install, operate, or transport the system.
- Install the system or DIN rail associated with, at a sturdy location
- Install the power socket outlet near the system where it is easily accessible
- Secure each system module(s) using its retaining screws
- Place power cords and other connection cables away from foot traffic. Do not place items over power cords and make sure they do not rest against data cables
- Shutdown, disconnect all cables from the system and ground yourself before touching internal modules
- Ensure that the correct power range is being used before powering the device
- Should a module fail, arrange for a replacement as soon as possible to minimize down-time
- By means of a power cord connected to a socket-outlet with earthing connection
- This product is intended to be supplied by a Listed Power Adapter or DC power source, rated 12-35Vdc, 16A, Tma 60 degree C and 5000m altitude during operation. If further assistance is required, please contact Neousys Technology
- If the system is not going to be used for a long time, disconnect it from mains (power socket) to avoid transient over-voltage

Mesures de sécurité

- Lire attentivement ces directives avant d'installer, d'utiliser ou de transporter le système.
- Installer le système ou la barrette DIN qui lui est associée, à un endroit solide
- Installer la prise de courant près du système et pour qu'elle soit facilement accessible
- Fixer chaque module du système à l'aide de ses vis de fixation
- Éloigner de la circulation piétonne les cordons d'alimentation et autres câbles de connexion. Ne jamais placer d'objets sur les cordons d'alimentation et s'assurer qu'ils ne reposent pas contre les câbles de données
- Avant de toucher les modules internes, arrêter, débrancher tous les câbles du système et raccordez-vous à la terre
- S'assurer que la bonne plage de puissance est utilisée avant d'alimenter l'appareil
- Prévoir un remplacement dès que possible en cas de défaillance d'un module, afin de minimiser les temps d'arrêt
- Au moyen d'un cordon d'alimentation branché à une prise de courant avec mise à la terre (MALT)
- Ce produit doit être alimenté par un adaptateur de courant homologué ou une source d'alimentation CC, de 12-35 Vcc et 16 A, conçue pour fonctionner à 60 °C Tma et à 5 000 m d'altitude. Communiquer avec Neousys Technology si de l'assistance supplémentaire est requise
- Si le système ne sera pas être utilisé pendant une période prolongée, le débrancher du réseau (prise de courant) pour éviter une surtension transitoire

Service and Maintenance

- ONLY qualified personnel should service the system
- Shutdown the system, disconnect the power cord and all other connections before servicing the system
- When replacing/ installing additional components (expansion card, memory module, etc.), insert them as gently as possible while assuring proper connector engagement

Avertissement concernant les piles

- Les piles risquent d'exploser si 10ece sont mal installées.
- Ne jamais essayer de recharger, d'ouvrir de force ou de chauffer les piles.
- Remplacer les piles uniquement avec le 10ece type ou l'équivalent recommandé par le fabricant.

Hot Surface Warning



A HOT SURFACE. DO NOT

TOUCH. "ATTENTION: Surface chaude. Ne pas toucher."

WARNING!

Components/ parts inside the equipment may be hot to touch! Please wait one-half hour after switching off before handling parts.

Surface chaude

AVERTISSEMENT : SURFACE CHAUDE. NE PAS TOUCHER.

Les composants et 11ecess à l'intérieur de l'équipement peuvent être chauds au toucher. Après l'arrêt, attendre au moins 30 minutes pour que le système refroidisse avant d'effectuer l'entretien.

 Respecter les règles de sécurité et d'entretien mentionnées au début du guide d'utilisation!

Battery Warning





- Batteries are at risk of exploding if incorrectly installed
- Do not attempt to recharge, force open, or heat the battery
- Replace the battery only with the same or equivalent type recommended by the manufacturer

Entretien et 12ecessarie

- La réparation du système ne peut être effectuée que par du personnel qualifié
- Avant de réparer le système, arrêter le système, débrancher le cordon d'alimentation et toutes les autres connexions
- Lors du remplacement ou de l'installation de composants supplémentaires (carte d'extension, module de mémoire, etc.), les insérer le plus doucement possible tout en s'assurant que les connecteurs sont bien engagés jusqu'au bout

ESD Precautions

- Handle add-on module, motherboard by their retention screws or the module's frame/ heat sink. Avoid touching the PCB circuit board or add-on module connector pins
- Use a grounded wrist strap and an anti-static work pad to discharge static electricity when installing or maintaining the system
- Avoid dust, debris, carpets, plastic, vinyl and 13ecessari in your work area.
- Do not remove any module or component from its anti-static bag before installation

Précautions 13ecessaries de décharge électrostatique (ESD)

- Tenir le module complémentaire et la carte mère par leurs vis de rétention ou le châssis/dissipateur de chaleur du module. Éviter de toucher la carte de circuit imprimé ou les broches du connecteur du module complémentaire
- Afin de décharger l'électricité statique, utiliser une dragonne mise à la terre et un tapis de travail antistatique lors de l'installation ou de l'entretien du système
- Éviter la poussière, les débris, les tapis, le plastique, le vinyle et la mousse de polystyrène dans votre zone de travail.
- Ne retirer aucun module ou composant de son sac antistatique avant l'installation

Restricted Access Location

The controller is intended for installation only in certain environments where both of the following conditions apply:

- Access can only be gained by QUALIFIED SERVICE PERSONNEL who have been instructed on the reasons for restrictions applied to the location and any precautions that shall be taken
- Access is through the use of a TOOL, lock and key, or other means of security, and is controlled by the authority responsible for the location

Lieu d'accès restreint

Le contrôleur doit être installé uniquement dans les environnements où les deux conditions suivantes sont présentes :

- Le lieu ne peut être accédé que par du PERSONNEL TECHNIQUE QUALIFIÉ informé des raisons des restrictions appliquées à l'emplacement et des précautions à prendre
- L'accès est contrôlé par l'autorité responsable de l'emplacement et se fait au moyen d'un OUTIL, d'une serrure et d'une clé ou d'autres moyens de sécurité

About This Manual

This manual introduces Neousys Nuvo-9160GC edge AI computer series featuring Intel[®] 13th/ 12th Gen Alder Lake Core[™] hybrid performance/ efficient core processors, and support for an NVIDIA GPU card.

Nuvo-9160GC supports an NVIDIA graphics card up to 130W. Nuvo-9166GC supports an NVIDIA L4 inference accelerator.

The guide also demonstrates the system's installation procedures.

Revision History

Version	Date	Description
1.0	Mar. 2023	Initial release
		Nuvo-9160GC specification update
1.1	May. 2023	Added support for Intel [®] 13 th Gen. CPU for Nuvo-9160GC series
		Added Nuvo-9166GC

1 Introduction

Nuvo-9160GC series is a rugged edge AI computer that delivers superior CPU and GPU performance by leveraging Intel's 13th/ 12th Gen platform and NVIDIA's graphics card to fuel real-time AI inference applications involving multiple cameras such as production line vision inspection, intelligent video analytics for surveillance or ITS, or autonomous mobile robot (AMR).

The Nuvo-9160GC supports an NVIDIA RTX graphics card up to 130W to offer approximately 9 TFLOPS of FP32 performance



Nuvo-9160GC

Nuvo-9166GC supports the data center grade NVIDIA[®] L4. Based on the NVIDIA[®] Ada Lovelace architecture for energy-efficient AI acceleration to offer 30.3 TFLOPS in FP32.





Benefiting from the cutting-edge Intel[®] 7 photolithography, Intel's 13th/ 12th Gen processors can offer up to 24 cores/ 32 threads with 1.8x the performance improvement compared to previous Intel 11th/ 10th Gen platforms. The platform is designed to accommodate the latest NVIDIA 130W RTX GPU or an NVIDIA L4 inference accelerator.

Nuvo-9160GC has a proven thermal design to guarantee reliable system operation from -25°C to 60°C. It features a passive-cooling design for the motherboard and segregated patented ventilation design* for the GPU accelerator card within Neousys' patented expansion Cassette*. The support of six GigE cameras (or IP cameras) and six USB3 cameras makes Nvuo-9160GC ideal for various vision-based AI application deployments. It also provides flexible data storage options, including one M.2 2280 Gen4x4 NVMe providing up to 7000 MB/s extreme read/write speeds and two 2.5" SATA HDD/SSD to expand storage capacity.

With performance enhancements and comprehensive I/Os, Nuvo-9160GC series is the perfect edge AI inference platform for industrial environments from factory automation, smart agriculture, and autonomous machines.

1.1 Product Specifications

1.1.1 Nuvo-9160GC Specifications

System Core		
System Core Processor	Supports Intel® 13th-Gen Core [™] CPU (LGA1700 socket, 65W/ 35W TDP) - Intel® Core [™] i9-13900E/ i9-13900TE - Intel® Core [™] i7-13700E/ i7-13700TE - Intel® Core [™] i5-13500E/ i5-13400E/ i5-13500TE - Intel® Core [™] i3-13100E/ i3-13100TE Supports Intel® 12th-Gen Core [™] CPU (LGA1700 socket, 35W/ 65W TDP) - Intel® Core [™] i9-12900E/ i9-12900TE - Intel® Core [™] i7-12700E/ i7-12700TE - Intel® Core [™] i5-12500E/ i5-12500TE - Intel® Core [™] i3-12100E/ i3-12100TE - Intel® Core [™] i3-12100E/ i3-12100TE - Intel® Core [™] i3-12100E/ i3-12100TE	
	- Intel® Celeron® G6900E/ G6900TE	
Chipset	Intel® Q670E Platform Controller Hub	
Graphics	Integrated Intel® UHD Graphics 770 (32EU)	
Memory	Up to 64GB DDR5 4800 (two SODIMM slots)	
AMT	Supports Intel vPro/ AMT 16.0	
ТРМ	Supports dTPM 2.0	
I/O Interface		
Ethernet port*	5x 2.5GbE by I225 and 1x GbE by I219 with screw-lock	
PoE+	Optional IEEE 802.3at PoE+ PSE for Port 3 ~ Port 6 (100 W total power budget)	
USB	 1x USB 3.2 Gen2x2 (20 Gbps) port in type-C connector with screw-lock 4x USB 3.2 Gen2x1 (10 Gbps) ports in type-A connectors 2x USB 3.2 Gen 1x1 (5 Gbps) ports in type-A connectors 2x USB 2.0 ports 	
Video Port	 1x VGA connector, supporting 1920 x 1200 resolution 1x DVI-D connector, supporting 1920 x 1200 resolution 1x DisplayPort connector, supporting 4096 x 2304 resolution 	
Serial Port	2x software-programmable RS-232/ 422/ 485 ports (COM1/ COM2) 2x RS-232 ports (COM3/ COM4)	
Audio	1x 3.5 mm jack for mic-in and speaker-out	

Storage Interface		
SATA HDD	2x internal SATA ports for 2.5" HDD/ SSD (up to 15mm thickness), supporting RAID 0/1	
M.2 NVMe	1x M.2 2280 M key NVMe socket (PCIe Gen4 x4) for NVMe SSD	
Internal Expansi	ion Bus	
	1x PCIe x16 slot@Gen3, 16-lanes PCIe signals in Cassette for installing an	
PCI Express	NVIDIA® graphics card up to 130W TDP (Max. graphics card dimension is	
Slot	188 mm(L) x 131 mm(W), dual slot allocation)	
Mini PCI-E	1x full-size mini PCI Express socket	
M.2	1x M.2 2242/ 3052 B key socket with SIM slot for M.2 5G/ 4G module	
Power Supply		
DC Input	1x 3-pin pluggable terminal block for 8~48VDC DC input	
Remote Ctrl.	1x 3-pin pluggable terminal block for remote control and PWR LED output	
&LED Output		
	CPU+GPU (RTX3050) full load without PoE	
	With i9-12900E (35W mode / PL2) + 130W GPU: 243.8W @ 48V	
	With i9-12900E (35W mode / PL1) + 130W GPU: 196.3W @ 48V	
	With i9-12900E (35W mode / PL2) + 130W GPU: 241.2W @ 24V	
	With i9-12900E (35W mode / PL1) + 130W GPU: 191.0W @ 24V	
Maximum	With i9-12900E (65W mode / PL2) + 130W GPU: 291.8W @ 48V	
Power	With i9-12900E (65W mode / PL1) + 130W GPU: 230.4W @ 48V	
Consumption**		
Consumption	With i9-12900E (65W mode / PL2) + 130W GPU: 280.8W @ 24V	
	With i9-12900E (65W mode / PL1) + 130W GPU: 225.1W @ 24V	
	With i9-12900E (MAX mode / PL2) + 130W GPU: 326.4W @ 48V	
	With i9-12900E (MAX mode / PL1) + 130W GPU: 228.9W @ 48V	
	With i9-12900E (MAX mode / PL2) + 130W GPU: 324.0W @ 24V	
	With i9-12900E (MAX mode / PL1) + 130W GPU: 224.8W @ 24V	
Mechanical		
Dimension	240 mm (W) x 225 mm (D) x 110.5 mm (H)	
Weight	4.4Kg (approx. without graphics card)	
Mounting	Wall mount kit (standard) or damping bracket (optional)	
Environmental		

	With 35W CPU and 130W GPU
Operating	-25°C ~ 60°C ***
	With 65W CPU
Temperature	-25°C ~ 60°C ***/ **** (configured as 35W TDP)
	-25°C ~ 50°C ***/ **** (configured as 65W TDP)
Storage	-40°C to 85°C
Temperature	
Humidity	10%~90% , non-condensing
Vibration	MIL-STD-810G, Method 514.6, Category 4
Shock	MIL-STD-810G, Method 516.6, Procedure I, Table 516.6-II
EMC	CE/ FCC Class A, according to EN 55032 & EN 55035

* Due to I225-IT specification limitation, for systems running 2.5G Ethernet link speeds, please limit the operating temperature to 60°C.

** System load (PL1) under 100W, the required DC input range is 8V to 48V

System load (PL1) between 100W to 180W, the required DC input range is 12V to 48V

System load (PL1) between 180W to 360W (single GPU), the required DC input range is 24V to 48V

***For sub-zero operating temperature, a wide temperature HDD or Solid State Disk (SSD) is required.


*** For CPU operating at 65W mode, the highest operating temperature shall be limited to 50°C and thermal throttling may occur when sustained full-loading applied. Users can configure CPU power in BIOS to allow higher operating temperature.

1.1.2 Nuvo-9166GC Specification


System Core		
Processor	Supporting Intel® 13th-Gen Core ™ CPU (LGA1700 socket, 65W/ 35W TDP) - Intel® Core ™ i9-13900E/ i9-13900TE - Intel® Core ™ i7-13700E/ i7-13700TE - Intel® Core ™ i5-13500E/ i5-13400E/ i5-13500TE - Intel® Core ™ i3-13100E/ i3-13100TE Supporting Intel® 12th-Gen Alder Lake Core ™ CPU (LGA1700 socket, 35W/ 65W TDP) - Intel® Core ™ i9-12900E/ i9-12900TE - Intel® Core ™ i7-12700E/ i7-12700TE - Intel® Core ™ i5-12500E/ i5-12500TE - Intel® Core ™ i3-12100E/ i3-12100TE - Intel® Core ™ i5-12500E/ i5-12500TE - Intel® Core ™ i5-12500E/ i5-12500TE - Intel® Core ™ i5-12500E/ i5-12500TE - Intel® Core ™ i5-12500E/ i3-12100TE - Intel® Celeron® G6900E/ G6900TE	
Chipset	Intel® Q670E Platform Controller Hub	
Graphics	Integrated Intel® UHD Graphics 770 (32EU)	
Memory	Up to 64 GB DDR5 4800 SDRAM (two SODIMM slots)	
АМТ	Supports Intel vPro/ AMT 16.0	
ТРМ	Supports dTPM 2.0	
I/O Interface		
Ethernet*	5x 2.5G Ethernet by I225-IT and 1x Gigabit Ethernet by I219-LM with screw-lock	
PoE+	Optional IEEE 802.3at PoE+ PSE for Port 3 ~ Port 6. 100W total power budget	
USB 3.2	1x USB 3.2 Gen2x2 (20 Gbps) port in type-C connector with screw-lock 4x USB 3.2 Gen2x1 (10 Gbps) ports in type-A connectors	
	2x USB 3.2 Gen1x1 (5 Gbps) ports in type-A connectors	
USB 2.0	2x USB 2.0 ports	
Video Port	1x VGA connector, supporting 1920 x 1200 resolution	
(Integrated	1x DVI-D connector, supporting 1920 x 1200 resolution	
Graphics)	1x DisplayPort connector, supporting 4096 x 2304 resolution	
Serial Port	2x software-programmable RS-232/ 422/ 485 ports (COM1/COM2)	
	2x RS-232 ports (COM3/COM4)	
Audio	1x 3.5 mm jack for mic-in and speaker-out	
Storage Interface		
SATA HDD	2x internal SATA port for 2.5" HDD/ SSD installation, supporting RAID 0/ 1	
M.2	1x M.2 2280 M key socket (PCIe Gen4 x4) for NVMe SSD	
Expansion Bus		
PCI Express	2x PCIe x16 slot@Gen3, 8-lanes PCIe signal in Cassette for installing NVIDIA® L4 GPU and one additional PCIe card	

Mini PCI Express	1x full-size mini PCI Express socket
M.2	1x M.2 3042/3052 B key socket with SIM slot for M.2 4G/ 5G module
Power Supply	
DC Input	1x 3-pin pluggable terminal block for 8 to 48V DC input (24V for Nuvo-9166GC-UL)
Remote Ctrl. & LED Output	1x 3-pin pluggable terminal block for remote control and PWR LED output
Mechanical	
Dimension	240 mm (W) x 225 mm (D) x 110.5 mm (H)
Weight	ТВО
Mounting	Wall-mount (standard) or damping bracket (optional)
Environmental	
Operating	With 35W CPU and NVIDIA L4 GPU
Temperature	-25°C to 60°C**
	With 65W CPU and NVIDIA L4 GPU
	-25°C to 60°C**/*** (configured as 35W TDP)
	-25°C to 50°C**/*** (configured as 65W TDP)
Storage Temperature	-40°C to 85°C
Humidity	10% to 90% , non-condensing
Vibration	MIL-STD-810H, Method 514.8, Category 4 (with optional damping bracket)
Shock	MIL-STD-810H, Method 516.8, Procedure I (with optional damping bracket)
EMC	CE/FCC Class A, according to EN 55032 & EN 55035

1.2 **Nuvo-9160GC Dimension**




1.2.1 **Nuvo-9160GC Front Panel View**




240.0


1.2.2 **Nuvo-9160GC Rear Panel View**



1.2.3 Nuvo-9160GC Side View




240.0




1.2.5 Nuvo-9160GC Bottom View

1.3 **Nuvo-9166GC Dimension**




1.3.1 **Nuvo-9166GC Front Panel View**




240.0


1.3.2 **Nuvo-9166GC Rear Panel View**



1.3.3 Nuvo-9166GC Side View



1.3.5 Nuvo-9166GC Bottom View



2 System Overview

Upon receiving and unpacking your Nuvo-9160GC series system, please check immediately if the package contains all the items listed in the following table. If any item(s) are missing or damaged, please contact your local dealer or Neousys Technology.

2.1 Packing List

System Pack	Nuvo-9160GC	Qty
	Nuvo-9160GC series system	1
I	(If you ordered CPU/ RAM/ HDD, please verify these items)	
	Accessory box, which contains	
	CPU bracket	1
	Wall-mount bracket	2
	Foot pad	4
	 3-pin push-in power terminal block 	2
2	 HDD thermal pad for 2.5" HDD/SSD (if HDD is not installed) 	1
2	Screw pack	1
	• Poron-C (36 x 6 x 6 mm)	2
	• Rubber cube (8 x 8 x 6mm)	3
	 M.2 standoff for B key 3042/ 3052 module 	1
	 6-pin to 8-pin graphics card power cable 	1
	 Screws for Sparkle RTX 3050 (M2,I,L6,D4.3,H0.8,BNi,Nylok) 	2

2.1.1 Nuvo-9160GC Series Packing List


System	Nuvo-9160GC	
Pack		
1	Nuvo-9166GC series system	1
	(If you ordered CPU/ RAM/ HDD, please verify these items)	1
	Accessory box, which contains	
	CPU bracket	1
	Wall-mount bracket	2
2	Foot pad	4
2	• 3-pin push-in power terminal block	2
	 HDD thermal pad for 2.5" HDD/SSD (if HDD is not installed) 	1
	Screw pack	1
	• M.2 standoff for B key 3042/ 3052 module	1

2.2 Front Panel I/O



For demonstration purposes, Nuvo-9160GC will be used in most illustrations. A dedicated illustration will be shown if the component is significantly different.


The Nuvo-9160GC series systems' front panel features the following external I/O connections.



No.	ltem	Description
1	<u>USB3.2</u>	USB3.1 Gen 2 port (SuperSpeed+) offers up to 10Gbps, twice the
	Gen2x1	bandwidth over existing SuperSpeed USB3.1 Gen. 1 connection. It is
	<u>port</u>	also backwards compatible with USB3.0 and USB2.0
2	<u>USB2.0</u>	The USB 2.0 ports offer up to 480Mbit/s bandwidth and are backward
2	<u>port</u>	compatible with USB 1.1/ 1.0.
3	<u>CMOS</u>	Lies this button to manually to react the CMOS to load default PIOS
3	reset button	Use this button to manually to reset the CMOS to load default BIOS
4	DVI port	DVI-D output supports resolution up to 1920 x 1200@60Hz and is
4		compatible with other digital connections via an adapter.
5	VGA port	VGA output supports resolution up to 1920 x 1200@60Hz
6	<u>USB3.1</u>	
	Gen1x1	USB3.1 Gen 1 offers up to 5Gbps of data-throughput performance
	<u>port</u>	
7	<u>DisplayPort</u>	Support display resolutions up to 4096 x 2304 @ 60Hz. Compatible with
		HDMI/ DVI via respective adapter/ cable (resolution may vary).


8	USB3.2 Gen2x2 Type-C port	The USB 3.2 Gen2x2 type-C port offers up to 20Gbps of bandwidth connectivity for fast data exchange with external devices
9	Ethernet &	1x GbE by I219 with screw-lock
_	PoE+ port	5x 2.5GbE by I225 with screw-lock
10	Reset	Lies this button to monuply need the system
10	button	Use this button to manually reset the system.
11	<u>LED</u>	From left to right, the LEDs are IGN (ignition control), WDT (watchdog
''	indicators	timer), HDD (hard disk drive) and PWR (system power).
	Power	
12	button	Use this button to turn on or shutdown the system.
		Nuvo-9160GC
		The Cassette module offers a separate compartment to manage thermal
en		conditions and reduce installation complications of an NVIDIA graphics
Gre	Cassette	card up to 130W for AI accelerated applications.
Area in Green	module	Nuvo-9166GC
Are		The Cassette module offers a separate compartment to manage thermal
		conditions and reduce installation complications of an NVIDIA L4
		graphics card for AI accelerated applications.

2.2.1 USB3.2 Gen2x1 Port



The system's USB 3.2 Gen2x1 ports (10Gbps) are implemented via native xHCI (eXtensible Host Controller Interface) controller and are backward compatible with USB3.2 Gen.1 USB 2.0, USB 1.1 and USB 1.0 devices. UFEI USB is also supported so you can use USB keyboard/ mouse in UEFI shell environment. Indicated in red are screw-lock holes for the corresponding USB port.

xHCI driver is supported natively in Windows 10, therefore you do not need to install the xHCI driver prior to utilizing USB functions.




2.2.2 USB2.0 Port

The USB2.0 ports are implemented via native xHCI (eXtensible Host Controller Interface) and are backward compatible with USB 1.1 and USB 1.0 devices. UEFI USB support is also provided so you can use USB keyboard/ mouse in UEFI shell environment. Indicated in **red** is a screw-lock hole for the corresponding USB port.

xHCI driver is supported natively in Windows 10, therefore you do not need to install xHCI driver to utilize USB functions.

2.2.3 CMOS Reset Button




The CMOS Reset button is used to manually reset the motherboard BIOS in case of system halt or malfunction. To avoid unexpected operation, it is purposely placed behind the panel. To reset, disconnect the DC power input, and use the tip of a pen to press and hold for at least 5 seconds to reset the BIOS.

WNOTE You **MUST** disconnect the DC input from the system before resetting the CMOS.



Clearing the CMOS will reset all BIOS settings to default and may result in down time!


2.2.4 DVI Port



DVI-D transmits graphics data in digital format and therefore can deliver better image quality at high resolution. The DVI connector on the front panel can either output DVI signals or other digital signals (via an adapter/ cable) depending on the display device connected. It supports resolutions up to 1920x1200@60Hz.

The system supports triple independent display outputs by connecting display devices to VGA, DVI and DisplayPort connection. To support multiple display outputs and achieve best DVI output resolution in Windows, you need to install corresponding graphics driver. Please refer to section <u>OS Support and Driver Installation</u> for details.

2.2.5 VGA Port




VGA connector is the most common video display connection. The VGA output supports up to 1920x1200@60Hz resolution.

The system supports triple independent display outputs by connecting display devices to VGA, DVI and DisplayPort connection. To support multiple display outputs and achieve best VGA output resolution in Windows, you need to install corresponding graphics drivers. Please refer to section <u>OS Support and Driver Installation</u> for details.




Please make sure your VGA cable includes SDA and SCL (DDC clock and data) signals for correct communication with monitor to get resolution/timing information. A cable without SDA/ SCL can cause blank screen on your VGA monitor due to incorrect resolution/timing output.

2.2.6 USB3.2 Gen 1x1 Port



The system's USB 3.2 Gen1x1 ports (5Gbps) are implemented via native xHCI (eXtensible Host Controller Interface) controller and are backward compatible with USB 2.0, USB 1.1 and USB 1.0 devices. UEFI USB is also supported so you can use USB keyboard/mouse in UEFI shell environment. Indicated in **red** is a screw-lock hole for the corresponding USB port. xHCI driver is supported natively in Windows 10, therefore you do not need to install the xHCI driver prior to utilizing USB functions.

2.2.7 DisplayPort



The system has a DisplayPort (DP) output which is a digital display interface that mainly connect video source and carry audio to a display device. When connecting a DP, it can deliver up to 4K UHD (4096 x 2304 @ 60Hz) in resolution. The system is designed to support passive DP adapter/ cable. You can connect to other display devices using DP-to-HDMI cable or DP-to-DVI cable.




DP-to-HDMI

DP-to-DVI


The system supports triple independent display outputs by connecting display devices to VGA, DVI and DisplayPort connection. To support multiple display outputs and achieve best DisplayPort output resolution in Windows, you need to install corresponding graphics drivers. Please refer to section <u>OS Support and Driver Installation</u> for details.

2.2.8 USB3.2 Gen2x2 Type-C Port



The system's USB 3.2 Gen2x2 type-C port offers up to 20Gbps of data transfer bandwidth, and is implemented via the native xHCI (eXtensible Host Controller Interface) controller. The port is backward compatible with USB3.2 Gen.1 USB 2.0, USB 1.1 and USB 1.0 devices via a USB hub (not included) to connect to external devices.

xHCI driver is supported natively in Windows 10, therefore you do not need to install the xHCI driver prior to utilizing USB functions.



2.5 Ethernet Port/ Optional PoE+ 2.2.9

The system offers one GbE port (in blue) and five 2.5GbE ports (in green and purple) with four optional Power over Ethernet ports (in green). All Ethernet ports feature panel screw fix holes for a firm connection (indicated in red). The port marked in blue is implemented using Intel® I219-LM controller that supports Wake-on-LAN and is also compatible with Intel® AMT (Active Management Technology) to support advanced features such as remote SOL desktop and remote on/ off control.

Power over Ethernet (PoE) supplies electrical power and data on a standard CAT-5/CAT-6 Ethernet cable. Acting as a PoE PSE (Power Sourcing Equipment), compliant with IEEE 802.3at, each PoE port (indicated in green) delivers up to 25W to a Powered Device (PD). The system has a total 100W power budget. PoE ports can automatically detect and determine if the connected device requires power or not, so it is compatible with standard Ethernet devices as well.

Each port has one dedicated PCI Express link for maximum network performance. Please refer to the table below for LED connection statuses.


LED Color	Status	Description
	Off	Ethernet port is disconnected
Orange	On	Ethernet port is connected and no data transmission
	Flashing	Ethernet port is connected and data is transmitting/receiving
Speed LED (L	.eft)	

Active/Link LED (Right)

LED Color	Status	Description
Green or	Off	10 Mbps
Orange	Green	100 Mbps
orango	Orange	1000/ 2500 Mbps


To utilize the Ethernet ports in Windows, you need to install corresponding driver for Intel[®] I225 and I219-LM controllers.

2.2.10 Reset Button



The reset button is used to manually reset the system in case of system halt or malfunction. To avoid unexpected reset, the button is purposely placed behind the panel. To reset, please use a pin-like object (eg. tip of a pen) to access the reset button


2.2.11 LED Indicators



There are four LED indicators on the I/O panel: IGN, WDT, HDD and PWR. The descriptions of these four LED are listed in the following table.


Indicator	Color	Description
IGN	Yellow	Ignition signal indicator, lit when IGN is high (12V/ 24V).
WDT	Yellow	Watchdog timer LED, flashing when WDT is active.
HDD	Red	Hard drive indicator, flashing when hard disk drive is active.
PWR	Green	Power indictor, lit when system is on.

2.2.12 Power Button




The power button is a non-latched switch for ATX mode on/off operation. To turn on the system, press the power button and the PWR LED should light-up green. To turn off the system, issuing a shutdown command in OS is preferred, or you can simply press the power button. To force shutdown when the system freezes, press and hold the power button for 5 seconds. Please note that there is a 5-second interval between on/off operations (i.e. once the system is turned off, there is a 5-second wait before you can power-on the system).

2.2.13 Cassette Module



Neousys' patented expansion Cassette (R.O.C. Patent No. M456527) provides a separated compartment to accommodate an add-on card. It effectively manages thermal conditions of both the system and the add-on card. The modular concept brought by Cassette module also reduces the complexity of installing and replacing an add-on card in the fanless controller. The Cassette module incorporates an innovative mechanical design to effectively deal with the heat generated by GPU. This patented architecture (R.O.C. Patent No. M534371) creates a sealed wind tunnel to bring in cold air to the GPU and expels hot air via a system fan. The design offers the system extreme stability and reliability.

2.3 Rear Panel I/O




Nuvo-9166GC-UL

The system's rear panel features MezIO[™] port, four (4) COM ports, 3-pin terminal and 3-pin on/ off control. The Cassette module can be located at the bottom of the enclosure. The connectors of the installed PCI or PCIe card within the Cassette module can be accessed from this side of the panel.

No.	Item	Description
4	MezlO™ I/O	Reserved for MezIO [™] I/O connector. Connector may vary
		depending on your choice of MezIO [™] module.
2	4-Pole 3.5mm	The 4-pole 3.5mm jack accepts microphone voice input and
2	headphone/	headphone speaker sound output.


	microphone jack	
3	COM ports 1-4	The four COM ports offer communication with external devices.
4	<u>3-pin terminal</u> block (DC/ ignition input)	Compatible with DC power input from 8-48V, the terminal block is also used for ignition signal input.
5	<u>3-pin remote on/</u> off control	Allows for external switch extension when the system is placed inside a cabinet.
Area in green	<u>Cassette</u> module	The cassette module offers a separate compartment to manage thermal conditions and reduce installation complications of an add-on card.



2.3.1 4-Pole 3.5mm Headphone/ Microphone Jack

The system audio function uses high definition audio. There is a female 4-pole Daudio jack for headphone (speaker) output and microphone input. The HD audio codec is natively supported in Windows 10 and Windows 11, and no additional drivers are required to enable the audio function on Nuvo-9000 series.

2.3.2 COM Ports




The system provides four COM ports for communicating with external devices. These COM ports are implemented using industrial-grade ITE8786 Super IO chip (-40 to 85°C) and provide up to 115200 bps baud rate.

COM1 and COM2 (in **red**) are software-configurable RS-232/ 422/ 485 ports. COM3 and COM4 (in **blue**) are standard 9-wire RS-232 ports. The operation mode of COM1 and COM2 can be set in BIOS setup utility. The following table describes the pin definition of COM ports.

COM Port Pin Definition

$$\bigcirc \begin{pmatrix} \bullet & \circ & \circ & \bullet \\ \bullet & \circ & \circ & \circ & \circ \\ \bullet & \circ & \circ & \circ & \circ \end{pmatrix} \bigcirc$$

		COM1 & CC	DM2	COM3 & COM4
Pin#	RS-232 Mode	RS-422 Mode	RS-485 Mode (Two-wire 485)	RS-232 Mode
1	DCD			DCD
2	RX	422 TXD+	485 TXD+/RXD+	RX
3	ТΧ	422 RXD+		ТХ
4	DTR	422 RXD-		DTR
5	GND	GND	GND	GND
6	DSR			DSR
7	RTS			RTS
8	CTS	422 TXD-	485 TXD-/RXD-	CTS
9	RI			RI



2.3.3 3-Pin Terminal Block for DC and Ignition Input


Nuvo-9166GC-UL

The system accepts a wide range of DC power input from 8 to 48V (24V for Nuvo-9166GC-UL) 3-pin pluggable terminal block, which is fit for field usage where DC power is usually provided. The screw clamping mechanism on the terminal block offers connection reliability when wiring DC power.

In addition to DC power input, this terminal block can also accept ignition signal input (IGN) when ignition control module (eg. MezIO-V20) is installed for in-vehicle applications.

Please make sure the voltage of DC power is correct before you connect it to the system. Supplying a voltage over 48V will damage the system.

2.3.4 3-Pin Remote On/ Off



The "Remote On/ Off" 3-pin connection allows for the connection of an external non-latched switch to turn on/ off the system. It is useful when the system is placed in a cabinet or a not easily accessed location. You may connect an external status LED (20mA) indicator by connecting to PWR LED and GND.

2.4 Internal I/O Functions

In addition to I/O connectors on the front panel, the system also provides internal on-board connectors, such as remote on/off control, LED status output, internal USB 2.0 ports, etc. In this section, we'll illustrate these internal I/O functions.

2.4.1 Dual SODIMM DRAM Slot



The system motherboard supports two DDR5 4800 SODIMMs memory module up to 64GB. Each slot supports single module SODIMM up to 32GB capacity.

🖉 NOTE


When changes are made to DRAM module(s), such as additionally install or remove and reinstall (into the same/ different slot), it will result in approximately a 30 to 60 seconds delay when booting up for the first time after such change(s).



2.4.2 mini-PCIe Socket & Pin Definition

The system provides a mini-PCIe socket (indicated in **blue**) that is in compliance with mini-PCIe specification rev. 1.2. This mini-PCIe socket is designed with SIM card (slot indicated in **red**) support. With a SIM card installed, your system can access the internet via your network provider's 4G/ 3G network.

For wireless (WiFi/ 4G/ 3G) communication, multiple SMA antenna apertures can be located on the front and rear panel.



Front panel antennae opening


Rear panel antennae opening

mini-PCIe socket definition

51	49	47	45	43	41	39	37	35	33	31	29	27	25	23	21	19	17	1	5	13	11	9	7	5	3	1
52	50	48	46	44	42	40	38	36	34	32	30	28	26	24	22	20	18	16	1	4	12	10	8	6	4	2

Pin	Signal (mPCle)	Pin #	Signal (mPCle)
1	WAKE#	2	+3.3Vaux
3	-	4	GND
5	-	6	+1.5V
7	CLKREQ#	8	UIM_PWR
9	GND	10	UIM_DATA
11	REFCLK-	12	UIM_CLK
13	REFCLK+	14	UIM_RESET
15	GND	16	UIM_VPP
Mecha	inical Key		
17	Reserved* (UIM_C8)	18	GND
19	Reserved* (UIM_C4)	20	W_DISABLE#
21	GND	22	PERST#
23	PERn0	24	3.3V
25	PERp0	26	GND
27	GND	28	+1.5V
29	GND	30	SMB_CLK
31	PETn0	32	SMB_DATA
33	PETp0	34	GND
35	GND	36	USB_D-
37	GND	38	USB_D+
39	3.3V	40	GND
41	3.3V	42	-
43	GND	44	-
45	Reserved	46	-
47	Reserved	48	+1.5V
49	Reserved	50	GND
51	Reserved	52	3.3V


Some off-the-shelf mini-PCIe 5G/4G modules are not compliant to standard mini-PCIe interface. They use 1.8V I/O signals instead of standard 3.3V I/O and may cause signal conflict. Please consult with Neousys for compatibility when in doubt! Installing an incompatible 4G module may damage the system or the module itself may be damaged.




2.4.3 M.2 2242/ 3042/ 3052 (B Key), Mini-SIM Card Slot & Pin Definition

The system has an M.2 2242/ 3042/ 3052 slot (indicated in **blue rectangle**) with a 5G/ 4G SIM slot (indicated in **red rectangle**). A copper standoff is provided for you to secure onto the motherboard into the **red arrow** location for an M.2 2242/ 3042 module, or into the **blue arrow** location for an M.2 3052 module. By installing a 5G or 4G M.2 module and SIM card, you can access the internet via the provider's network.

For wireless 5G/4G, SMA antenna apertures are located on front/ rear panels.





Front panel antennae opening

Rear panel antennae opening

2 10 20 74 Pin # Signal Pin # Signal 1 - 2 +3V3 3 GND 4 +3V3 5 GND 6 FULL CARD POWER OFF N 7 USB D+ 8 W_DISABLE_N 9 USB D- 10 - 11 GND - - 21 - 20 - 23 - 22 - 25 - 24 - 27 GND 26 - 29 USB3.0-RX+ 28 - 21 - 22 - 25 - 24 - 27 GND 26 - 29 USB3.0-RX+ 28 - 33 GND 32 UIM1-CLK 35 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - </th <th>1</th> <th>11 21</th> <th></th> <th>75</th>	1	11 21		75
Pin # Signal Pin # Signal 1 - 2 +3V3 3 GND 4 +3V3 5 GND 6 FULL_CARD_POWER_OFF_N 7 USB_D+ 8 W_DISABLE_N 9 USB_D- 10 - 11 GND - - 23 - 22 - 25 - 24 - 27 GND 26 - 29 USB_0-RX- 28 - 31 USB_3.0-RX- 28 - 33 GND 32 UIM1-RESET 33 GND 32 UIM1-RESET 33 GND 33 - 41 PER0 / SATA-B+ 40 UIM2-DET 43 PER0 / SATA-B- 42 UIM2-DATA 45 GND 44 UM2-DATA 45 GND 50 PERST_N 53				
1 - 2 +3V3 3 GND 4 +3V3 5 GND 6 FULL_CARD_POWER_OFF_N 7 USB_D+ 8 W_DISABLE_N 9 USB_D- 10 - 11 GND - - 23 - 22 - 25 - 24 - 27 GND 26 - 29 USB_0-RX- 28 - 31 USB_3.0-RX- 28 - 33 GND 32 UIIM1-RESET 33 GND 32 UIM1-CLK 35 USB_3.0-TX- 34 UIM1-DATA 37 USB_3.0-TX- 34 UIM1-DATA 37 USB_3.0-TX- 34 UIM1-DLK 38 GND 38 - 41 PERn0 / SATA-B- 42 UIM2-DET 43 PERp0 / SATA-A- 46 UIM2-RST				
3 GND 4 +3V3 5 GND 6 FULL_CARD_POWER_OFF_N 7 USB_D+ 8 W_DISABLE_N 9 USB_D- 10 - 11 GND - - 21 - 20 - 23 - 22 - 25 - 24 - 27 GND 26 - 29 USB3.0-RX- 28 - 31 USB3.0-RX- 30 UIM1-RESET 33 GND 32 UIM1-CLK 35 USB3.0-TX- 34 UIM1-DATA 37 USB3.0-TX- 34 UIM1-PWR 39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-RST 49 PETp0 / SATA-A- 46 UIM2-RST				
5 GND 6 FULL_CARD_POWER_OFF_N 7 USB_D+ 8 W_DISABLE_N 9 USB_D- 10 - 11 GND - - 21 - 20 - 23 - 22 - 25 - 24 - 27 GND 26 - 29 USB3.0-RX- 28 - 31 USB3.0-RX+ 30 UIM1-RESET 33 GND 32 UIM1-CLK 35 USB3.0-TX- 34 UIM1-DATA 37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PER0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B+ 42 UIM2-DATA 45 GND 44 UIM2-CLK 47 PETn0 / SATA-A+ 46 UIM2-PWR 51 GND 50 PERST_N				
7 USB_D+ 8 W_DISABLE_N 9 USB_D- 10 - 11 GND - 23 - 22 - 25 - 24 - 27 GND 26 - 29 USB3.0-RX- 28 - 31 USB3.0-RX+ 30 UIM1-RESET 33 GND 32 UIM1-CLK 35 USB3.0-TX+ 36 UIM1-DATA 37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKN 52 - 56 - 58 - 57 GND				
9 USB D- 10 - 11 GND Mechanical Key 21 - 20 - 23 - 22 - 25 - 24 - 27 GND 26 - 29 USB3.0-RX- 28 - 31 USB3.0-RX+ 30 UIM1-RESET 33 GND 32 UIM1-CLK 35 USB3.0-TX- 34 UIM1-DATA 37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-DET 43 PERp0 / SATA-A- 46 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKP 54 - 57			-	
Mechanical Key 21 - 20 - 23 - 22 - 25 - 24 - 27 GND 26 - 29 USB3.0-RX- 28 - 31 USB3.0-RX+ 30 UIM1-RESET 33 GND 32 UIM1-CLK 35 USB3.0-TX- 34 UIM1-DATA 37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-CLK 47 PETn0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST 49 PETp0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST 53 REFCLKN 52 - 55 REFCLKP </th <th></th> <th></th> <th></th> <th>W_DISABLE_N</th>				W_DISABLE_N
Mechanical Key 21 - 20 - 23 - 22 - 25 - 24 - 27 GND 26 - 29 USB3.0-RX- 28 - 31 USB3.0-RX+ 30 UIM1-RESET 33 GND 32 UIM1-CLK 35 USB3.0-TX- 34 UIM1-DATA 37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-CLK 47 PETn0 / SATA-A- 46 UIM2-RST 49 PETp0 / SATA-A- 46 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKP 54 - 57 GND <t< th=""><th></th><th></th><th>10</th><th>-</th></t<>			10	-
21 - 20 - 23 - 22 - 25 - 24 - 27 GND 26 - 29 USB3.0-RX- 28 - 31 USB3.0-RX+ 30 UIM1-RESET 33 GND 32 UIM1-CLK 35 USB3.0-TX- 34 UIM1-DATA 37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B+ 42 UIM2-DATA 45 GND 44 UIM2-CLK 47 PETn0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKN 52 - 56 - 56 - 57 GND 56 - 59 - 58 - 61 - 60 - <th>11</th> <th></th> <th></th> <th>_</th>	11			_
23 - 22 - 25 - 24 - 27 GND 26 - 29 USB3.0-RX- 28 - 31 USB3.0-RX+ 30 UIM1-RESET 33 GND 32 UIM1-CLK 35 USB3.0-TX- 34 UIM1-DATA 37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-CLK 47 PETn0 / SATA-A- 46 UIM2-RST 49 PETp0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKN 52 - 56 - 66 - 59 - 58 -		Mec	chanical l	Key
25 - 24 - 27 GND 26 - 29 USB3.0-RX- 28 - 31 USB3.0-RX+ 30 UIM1-RESET 33 GND 32 UIM1-CLK 35 USB3.0-TX- 34 UIM1-DATA 37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-DET 45 GND 44 UIM2-DET 45 GND 44 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKN 52 - 56 - 58 - 61 - 60 - 63 - 62 - 65 <		-	-	-
27 GND 26 - 29 USB3.0-RX- 28 - 31 USB3.0-RX+ 30 UIM1-RESET 33 GND 32 UIM1-CLK 35 USB3.0-TX- 34 UIM1-DATA 37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-DET 45 GND 44 UIM2-DET 45 GND 44 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKN 52 - 56 - 58 - 61 - 60 - 59 - 58 - 61 - 66 UIM1_DETECT 69		-		-
29 USB3.0-RX- 28 - 31 USB3.0-RX+ 30 UIM1-RESET 33 GND 32 UIM1-CLK 35 USB3.0-TX- 34 UIM1-DATA 37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-CLK 47 PETn0 / SATA-A- 46 UIM2-RST 49 PETp0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKN 52 - 56 - 66 - 59 - 58 - 61 - 62 -<	25	-	24	-
31 USB3.0-RX+ 30 UIM1-RESET 33 GND 32 UIM1-CLK 35 USB3.0-TX- 34 UIM1-DATA 37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-CLK 47 PETn0 / SATA-A- 46 UIM2-RST 49 PETp0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKP 54 - 57 GND 56 - 59 - 58 - 61 - 60 - 63 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 -	27	GND	26	-
33 GND 32 UIM1-CLK 35 USB3.0-TX- 34 UIM1-DATA 37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PERn0/SATA-B+ 40 UIM2-DET 43 PERp0/SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-CLK 47 PETn0/SATA-A- 46 UIM2-RST 49 PETp0/SATA-A+ 48 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKP 54 - 57 GND 56 - 59 - 58 - 61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 <th>29</th> <th>USB3.0-RX-</th> <th>28</th> <th>-</th>	29	USB3.0-RX-	28	-
35 USB3.0-TX- 34 UIM1-DATA 37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-CLK 47 PETn0 / SATA-A- 46 UIM2-RST 49 PETp0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKP 54 - 57 GND 56 - 59 - 58 - 61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 7	31	USB3.0-RX+	30	UIM1-RESET
37 USB3.0-TX+ 36 UIM1-PWR 39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-CLK 47 PETn0 / SATA-A- 46 UIM2-RST 49 PETp0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKN 52 - 57 GND 56 - 59 - 58 - 61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	33	GND	32	UIM1-CLK
39 GND 38 - 41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-CLK 47 PETn0 / SATA-A- 46 UIM2-RST 49 PETp0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKP 54 - 57 GND 56 - 59 - 58 - 61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	35	USB3.0-TX-	34	UIM1-DATA
41 PERn0 / SATA-B+ 40 UIM2-DET 43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-CLK 47 PETn0 / SATA-A- 46 UIM2-RST 49 PETp0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKP 54 - 57 GND 56 - 59 - 58 - 61 - 60 - 63 - 62 - 64 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	37	USB3.0-TX+	36	UIM1-PWR
43 PERp0 / SATA-B- 42 UIM2-DATA 45 GND 44 UIM2-CLK 47 PETn0 / SATA-A- 46 UIM2-RST 49 PETp0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKP 54 - 57 GND 56 - 59 - 58 - 61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	39	GND	38	-
45 GND 44 UIM2-CLK 47 PETn0 / SATA-A- 46 UIM2-RST 49 PETp0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKP 54 - 57 GND 56 - 59 - 58 - 61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	41	PERn0 / SATA-B+	40	UIM2-DET
47 PETn0 / SATA-A- 46 UIM2-RST 49 PETp0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKP 54 - 57 GND 56 - 59 - 58 - 61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	43	PERp0 / SATA-B-	42	UIM2-DATA
49 PETp0 / SATA-A+ 48 UIM2-PWR 51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKP 54 - 57 GND 56 - 59 - 58 - 61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	45	GND	44	UIM2-CLK
51 GND 50 PERST_N 53 REFCLKN 52 - 55 REFCLKP 54 - 57 GND 56 - 59 - 58 - 61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	47	PETn0 / SATA-A-	46	UIM2-RST
53 REFCLKN 52 - 55 REFCLKP 54 - 57 GND 56 - 59 - 58 - 61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	49	PETp0 / SATA-A+	48	UIM2-PWR
55 REFCLKP 54 - 57 GND 56 - 59 - 58 - 61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	51	GND	50	PERST_N
57 GND 56 - 59 - 58 - 61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	53	REFCLKN	52	-
59 - 58 - 61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	55	REFCLKP	54	-
61 - 60 - 63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	57	GND	56	-
63 - 62 - 65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	59	-	58	-
65 - 64 - 67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	61	-	60	-
67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	63	-	62	-
67 RESET_N 66 UIM1_DETECT 69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3	65	-	64	
69 CONFIG_1 68 - 71 GND 70 +3V3 73 GND 72 +3V3		RESET_N	66	UIM1_DETECT
71 GND 70 +3V3 73 GND 72 +3V3				
73 GND 72 +3V3				+3V3
	75		74	+3V3

M.2 (B Key) Slot Pin Definition

2.4.4 SATA Ports



The system has four SATA ports which support Gen3, 6 Gb/s SATA signals. Each SATA port (indicated in **blue**) features a 7-pin SATA connector. However, due to mechanical restrictions, only two SATA ports can be accommodated inside the Nuvo-9000 series.

The two power connectors (indicated in **red**) can accommodate a 2.5" HDD/ SSD each in the internal HDD bracket. Standard 22-pin SATA connectors are provided with the system. You may refer to the SATA Configuration section for SATA settings.



Supports up to 15mm thickness HDD/ SSD.


2.4.5 DIP Switch



The DIP switch (indicated in **blue**) should be already configured out of the factory. Users need only set the 4th DIP switch to ON for BIOS update and switch it back to the OFF position when BIOS upgrade has completed. The table below shows the system default DIP switch settings for reference purposes.

System	Default DIP switch setting	Enable BIOS upgrade
Nuvo-9160GC	$ \begin{array}{c c} ON & DIP \\ \hline 1 & 2 & 3 & 4 \end{array} $	$ \begin{array}{c c} ON & DIP \\ \hline 1 & 2 & 3 & 4 \end{array} $
Nuvo-9166GC	$ \begin{array}{c c} ON & DIP \\ \hline 1 & 2 & 3 & 4 \end{array} $	$ \begin{array}{c c} ON & DIP \\ \hline 1 & 2 & 3 & 4 \end{array} $

Changing any DIP switches to the ON or OFF position will result in extra detection time during the start up process.




2.4.6 On/ Off Ctrl & Status Output

Pin#	Definition	Description
1	WDT_LED-	[Output] Watchdog timer indicator, flashing when Watchdog
2	WDT_LED+	timer is active
3	Standby Power-	[Output] Standby power indicator, on if DC power is applied
4	Standby Power+	and system is in S5 (standby) mode.
5	HDD-	[Output] Hard drive indicator, flashing when SATA hard
6	HDD+	drive is active.
7	Power-	[Output] System power indicator, on if system is turned on,
8	Power+	off if system is turned off.
9	Ctrl-	[Input] Remote on/off control, connects to an external
10	Ctrl+	switch to turn on/off the system (polarity is negligible).
11	IGN_LED-	[Output] Ignition control indicator, on if ignition control is on,
12	IGN_LED+	off if ignition control is off.

2.4.7 Internal USB 2.0 Port



The system's motherboard has an internal USB2.0 port on the PCBA. You can utilize this USB port to connect a USB protection dongle inside the chassis of the system.



2.4.8 M.2 2280 (M Key) Slot for NVMe SSD

The system has a Gen4 x4 PCIe M.2 2280 slot for you to install an NVMe SSD. The M.2 NVMe SSD offers significantly better system performances when compared to a 2.5" SSD.

1	11 21		57 6
2	10 20		.
Pin #	Signal	Pin #	Signal
1	GND	2	+3V3
3 5	GND DEBN2	4	+3V3
	PERN3	6	-
7 9	PERP3 GND	<u> </u>	 DAS/DSS_N
9 11	PETN3	10	DAS/DSS_N +3V3
13	PETP3	12	+3V3 +3V3
15	GND	14	+3V3 +3V3
17	PERN2	18	+3V3
19	PERP2	20	-
21	GND	20	
23	PETN2	24	
25	PETP2	26	-
27	GND	28	-
29	PERN1	30	-
31	PERP1	32	-
33	GND	34	-
35	PETN1	36	-
37	PETP1	38	-
39	GND	40	-
41	PERn0	40	-
43	PERp0	44	-
45	GND	46	-
47	PETn0	48	-
49	PETp0	50	PERST_N
51	GND	52	
53	REFCLKN	54	-
55	REFCLKP	56	-
57	GND	58	-
		chanical Key	
67	-	68	SUSCLK
69	PEDET	70	+3V3
71	GND	72	+3V3
73	GND	74	+3V3
75	GND		

M.2 (M Key) Slot Pin Definition




2.4.9 MezIO[™] Interface & Pin Definition

MezIO[™] is an innovative interface designed for integrating application-oriented I/O functions into an embedded system. It offers computer signals, power rails and control signals via a high-speed connector. MezIO[™] is also mechanically reliable benefited from its 3-point mounted mezzanine structure. A MezIO[™] module can leverage these signals to implement comprehensive I/O functions.

The system incorporates MezIO[™] interface and universal mechanical design to accommodate Neousys' standard MezIO[™] modules. For customers who want to develop their own MezIO[™] module, Neousys provides MezIO[™] design documents on a NDA basis. Please contact Neousys for further information.

MezIO[™] Interface Pin Definition

MezIO[™] interface leverages FCI BergStak® board-to-board connector to provide interconnectivity of high-speed signals. The receptacle part on the PCBA is FCI 61082-063402LF while the plug part on the MezIO[™] module is FCI 61083-064402LF. Please refer to the following table for signal definition of its 60-pin connector.



Function	Signal	Pin#	Pin#	Signal	Function
Description					Description
Reserved	Reserved	1	2	PCIE_TXP_0	PCIe data pair
Reserved	Reserved	3	4	PCIE_TXN_0	PCIe data pair
Reserved	Reserved	5	6	GND	Ground
Reserved	Reserved	7	8	PCIE_RXP_0	PCIe data pair
System S4 signal	SLP_S4#	9	10	PCIE_RXN_0	PCIe data pair
Ground	GND	11	12	CLK100_P_0	PCIe clock pair
Reserved	Reserved	13	14	CLK100_N_0	PCIe clock pair
Ground	GND	15	16	GND	Ground
Reserved	UID_LED	17	18	PCIE_TXP_1	PCIe data pair
Platform reset	PLT_RST#	19	20	PCIE_TXN_1	PCIe data pair
USB data pair	USBP5_N	21	22	PCIE_RXP_1	PCIe data pair
USB data pair	USBP5_P	23	24	PCIE_RXN_1	PCIe data pair
Ground	GND	25	26	GND	Ground
SMB bus	SMB_DATA	27	28	CLK100_P_1	PCIe clock pair
SMB bus	SMB_CLK	29	30	CLK100_N_1	PCIe clock pair
PCIe data pair	PCIE_TXP_3	31	32	GND	Ground
PCIe data pair	PCIE_TXN_3	33	34	PCIE_TXP_2	PCIe data pair
Ground	GND	35	36	PCIE_TXN_2	PCIe data pair
PCIe data pair	PCIE_RXP_3	37	38	GND	Ground
PCIe data pair	PCIE_RXN_3	39	40	PCIE_RXP_2	PCIe data pair
Power button	PWRBTN#	41	42	PCIE_RXN_2	PCIe data pair
Reserved	Reserved	43	44	RXD4	SIO COM4
PCH GPIO	GPIO_RISER3	45	46	TXD4	SIO COM4
PCH GPIO	GPIO_RISER2	47	48	RXD5	SIO COM5
PCH GPIO	GPIO_RISER1	49	50	TXD5	SIO COM5
Ground	GND	51	52	GND	Ground
3.3V power	P3V3	53	54	P1V8	1.8V power
3.3V power	P3V3	55	56	GND	Ground
5V power	P5V	57	58	P12V	12V power
5V power	P5V	59	60	P12V	12V power

3 System Installation

Before disassembling the system enclosure and installing components and modules, please make sure you have done the following:


- It is recommended that only qualified service personnel should install and service this product to avoid injury or damage to the system.
- Please observe all ESD procedures at all times to avoid damaging the equipment.
- Before disassembling your system, please make sure the system has powered off, all cables and antennae (power, video, data, etc.) are disconnected.
- Place the system on a flat and sturdy surface (remove from mounts or out of server cabinets) before proceeding with the installation/ replacement procedure.

If your system has a dedicated graphics card installed, please follow the instructions to install <u>the wall mount bracket</u> onto the bottom of the enclosure to airflow to cool the graphics card.

3.1 Disassembling the System

To access system internal components, the system needs to be disassembled. To disassemble the system enclosure, you need to remove the Cassette module and screws on both I/O panels.

 Turn the system upside-down and remove the four screws (indicated in blue) at the bottom of the Cassette module.




2. Gently wiggle and separate the Cassette module from the system.






3. On the front I/O panel, remove the hexa-screws indicated below.


4. Remove the front I/O panel.




5. On the rear I/O panel, remove the hexa-screws indicated below.



6. Remove the rear I/O panel.



7. Gently lift the system's bottom panel.




8. Once the bottom panel has been removed, you should have access to the system's internal I/O interfaces.



3.2 Installing Internal Components

3.2.1 CPU Installation for Barebone System

- 1. To gain access to internal components, please refer to the section "<u>Disassembling the</u> <u>system</u>".
- 2. To install the CPU, you will need to separate the heatsink and the motherboard.
- 3. To do so, remove the four screws indicated below.



4. Gently separate the motherboard from the heatsink, you'll see the CPU socket protective cover, place finger tips underneath the sign "REMOVE" for leverage and gently lift the cover.



CPU protective cover

With the protective cover removed, please be careful when handling the motherboard. DO NOT touch the pins in the LGA socket!


Remove the CPU from its container/ tray. Match the four notches on the side (indicated by the blue arrows) to the protrusions in the socket, gently lower the CPU into the socket.
 Pay attention to the seating orientation, notice there is a short side (indicated by green lines), and a long side (indicated by red lines).




6. Locate the CPU retention bracket (holder) from the accessory box. Place the retention bracket on the CPU and hold it in place. Make sure the indicator triangle engraved on the CPU's integrated heat spreader (HIS) and the triangle indicator on the retention bracket are positioned in the same corner (indicated by blue circles).




 Turn the motherboard around while holding the CPU retention bracket in-place, and secure the bracket by tightening two M3 P-head screws on the other side of the motherboard.



8. Remove all thermal pads' protective films on the heatsink.



 With the four motherboard standoffs aligned, gently lower the motherboard onto the heatsink and secure the four screws. Please remember to remove the protective film (indicated in red) on the CPU's thermal pad as well.




Four standoffs on the heatsink



Secure motherboard with four screws


10. Once the motherboard has been installed, you're ready to secure the four screws that help the heatsink apply pressure to the CPU/ chipset die. You'll want to apply even pressure to the corners by gradually tightening each screw. Please refer to the recommended order when tightening the screws.



- 11. Reinstall the system panels, enclosure and Cassette module when done.
- 12. If you need to install other components, please refer to respective sections.

3.2.2 Remove and Replace the Existing CPU

- 1. To gain access to internal components, please refer to the section "Disassembling the system".
- 2. To replace the existing CPU, you will need to separate the heatsink and the motherboard.
- 3. To do so, remove the eight screws indicated below.



4. Remove the screws indicated once you separate the heatsink from the motherboard to remove the CPU holder.



5. At this point, the CPU and retention bracket may be stuck onto the heatsink (due to the thermal pad). Please use a plastic pry tool and gentle separate the CPU/ holder from the heatsink.



With the heatsink, CPU, and retention bracket removed, please be careful when handling the motherboard. DO NOT touch the pins in the LGA socket!


6. Gently separate the CPU from the retention bracket, and clean off any thermal pad residues on the heatsink and on the retention bracket.



CPU retention bracket (holder)



With the CPU removed, please be careful when handling the motherboard. DO NOT touch the pins in the LGA socket!



7. Place a new CPU thermal pad (indicated in **blue**) onto the heatsink for the new CPU.


8. Remove and clean off any thermal pad residues around the socket/ motherboard. Gently place the new CPU into the socket by matching the four notches (indicated by blues arrows) on the side to the protrusions in the socket. Pay attention to the seating orientation, notice there is a short side (indicated by green lines), and a long side (indicated by red lines).



9. Make sure all thermal pad residues have been cleaned on both sides of the retention bracket. Place the CPU retention bracket (holder) on top of the CPU and hold it in place. Make sure the indicator triangle engraved on the CPU's integrated heat spreader (HIS) and the triangle indicator on the retention bracket are positioned in the same corner (indicated by blue circles).




10. Turn the motherboard around and secure the bracket by tightening two M3 P-head screws.




Hold CPU bracket firmly and turn the motherboard around

Secure two M3 P-head screws

11. Align the motherboard to the four standoffs on the heatsink, gently lower the motherboard onto the heatsink and secure with four screws.



12. Once the motherboard has been installed, you're ready to secure the four screws that help the heatsink apply pressure to the CPU/ chipset die. You'll want to apply even pressure to the corners by gradually tightening each screw. Please refer to the recommended order when tightening the screws.



- 13. Reinstall the system panels, enclosure, and Cassette module when done.
- 14. If you need to install other components, please refer to respective sections.

3.2.3 DDR5 SO-DIMM Installation

There are two SO-DIMM memory slots (indicated in **blue**) on the motherboard that supports a total maximum of 64GB DDR5-4800. Please follow the procedures below to replace or install the memory modules.

- 1. Please refer to the section "Disassembling the System".
- 2. Locate the SODIMM memory module slots on the motherboard.




3. To install the memory module, insert gold fingers into the slot at 45-degree angle, push down on the memory module to clip the module into position.



4. Push the memory module down until it is clipped-in.



- 5. Repeat steps 3 and 4 to install the other module.
- 6. Before you reinstall the system enclosure, please remove the respective thermal pad protective film located on the enclosure's bottom panel.



- 7. <u>Reinstall the system enclosure</u> and panel when done.
- 8. If you need to install other components, please refer to respective sections.


3.2.4 mPCIe Module, Mini-SIM (2FF) Card and Antenna Installation

The system has an mPCIe slot (indicated in **blue**) coupled with Mini-SIM socket (indicated in **red**)for installing 3G/ 4G module. For installation, please refer to the following instructions.


- 1. Please refer to the section "Disassembling the System".
- 2. Locate the mPCIe and SIM card slots on the motherboard.



 Before installing the mPCIe module, you need to insert the Mini-SIM card. Slide the SIM slot holder and lift the SIM card holder. Insert the Mini-SIM card (pins facing up), shut the SIM holder and slide it to lock the SIM card in-place.




Slide and lift SIM card holder



Insert Mini-SIM card with pins facing up


4. Secure the Mini-SIM card by sliding the holder.



5. Insert the mPCIe module on a 45 degree angle into the mPCIe slot and secure the module.




Insert on 45 degree angle



Secure the module

6. Clip on the IPEX-to-SMA cable to the module and secure the antenna to the front or rear panel. Please refer to the module's manual for clip-on connection.





Clip on IPEX-to-SMA cable


Secure antenna to rear panel

- 7. <u>Reinstall the system enclosure</u> and panel when done.
- 8. If you need to install other components, please refer to respective sections.

3.2.5 M.2 2242/ 3042/ 3052 (B Key) Module and Micro-SIM (3FF) Card Installation

The system has an M.2 slot (indicated in **blue rectangle**) for installing 5G/4G with a micro-SIM card or a WiFi module card slots (indicated in **red rectangle**).For installation, please refer to the following instructions.

- 1. Please refer to the section "Disassembling the System".
- Locate the M.2 2242/ 3042/ 3052 (B Key) and SIM card slots on the motherboard. A copper standoff is provided for you to secure onto the motherboard into the red arrow location for an M.2 2242/ 3042 module, or into the blue arrow location for an M.2 3052 module.



3. Insert the module on a 45 degree angle.




4. Gently press down and secure the module with an M2.5 P-head screw.



5. Clip on the IPEX-to-SMA cable to the module and secure the antenna to the front or rear panel. Please refer to the module's manual for clip-on connection.






Clip on IPEX-to-SMA cable

Secure antenna to rear panel

- 6. <u>Reinstall the system enclosure</u> and panel when done.
- 7. If you need to install other components, please refer to respective sections.



3.2.6 M.2 2280 NVMe SSD Installation

The system has a Gen4 x4 PCIe M.2 2280 slot for you to install an NVMe SSD. For installation, please refer to the following instructions.

1. Please refer to the section "<u>Disassembling the System</u>", you may not need to completely dismantle the system to gain access to the M.2 slot.



2. Insert the module on a 45 degree angle.

3. Gently press down and secure the module with an M2.5 P-head screw.



4. Remove the thermal pad's protective film at the bottom of the enclosure panel for the NVMe module.



- 5. <u>Reinstall the system enclosure</u> and panel when done.
- 6. If you need to install other components, please refer to respective sections.



3.2.7 MezIO[™] Module Installation

MezIOTM is an innovative interface designed for integrating application-oriented I/O functions into an embedded system. It offers computer signals, power rails and control signals via a high-speed connector. MezIOTM is also mechanically reliable benefited from its 3-point mounted mezzanine structure. A MezIOTM module can leverage these signals to implement comprehensive I/O functions.

The system incorporates MezIO[™] interface and universal mechanical design to accommodate Neousys' standard MezIO[™] modules. For customers who want to develop their own MezIO[™] module, Neousys provides MezIO[™] design documents on a NDA basis. Please contact Neousys for further information.

 Please refer to the section "<u>Disassembling the System</u>", you may not need to completely dismantle the system to gain access to the MezIOTM interface. 2. The MezIO[™] module is secured by the three stand-mounts indicated in the illustration below.



3. Gently lower the MezIO[™] module onto the three stand-mounts while matching the MezIO[™] interface. Secure the module using three screws supplied.




- 4. <u>Reinstall the system enclosure</u> and panel when done.
- 5. If you need to install other components, please refer to respective sections.

3.2.8 HDD/ SSD Installation



Supports up to 15mm thickness HDD/ SSD.



The system has two SATA ports (indicated in **blue**) and two four pin power connectors (indicated in **red**). The SATA and power cables should already be connected on the motherboard so users only need to install the HDD/ SSD. Please refer to the following instructions on how to install 2.5" SATA HDD/SSD.

1. Turn the system upside-down and remove the three screws indicated in the illustration below and lift the tray out of the system.



2. Gently pry open the hard drive cage.



3. Take the HDD/ SSD thermal pad (if not already attached) out of the accessory box and place it in the middle of the tray. Remove the protective film covering the HDD/ SSD thermal pad.



4. Place the HDD/ SSD (with labels facing up), match the SATA connector end to the side with two screw holes (indicated in **blue**), secure the HDD/ SSD with the supplied flathead screws (4 per drive).



5. Connect the 22-pin SATA cable to the installed HDD/ SSD.



6. Gently put the tray back into the system with the connector side being inserted into the system first and secure the tray with three screws.



7. If you need to install other components, please refer to respective sections.

3.2.9 Ethernet/ PoE+ Port Panel Screw Fix

The system's RJ45 Ethernet ports have panel screw fix holes to secure the cable connection.



1. To install and make use to the panel screw fix connection, you must acquire panel screw fix cables such as the cable shown below.



2. Simply insert the RJ45 connector into the RJ45 port and secure the top and bottom screws using your fingers or a screw driver.





Ports 5 and 6 have only the bottom panel screw fix hole.

3.3 Nuvo-9160GC Graphics Card Replacement/ Installation



Once you have installed the dedicated graphics card, please install the wall mount bracket onto the bottom of the enclosure to airflow to cool the graphics card during operation.




The Cassette module compartmentalizes the heat generated and effectively manages thermal conditions of both the system and graphics card. The modular design reduces the complexity of installing and replacing graphics cards in the fanless controller. In addition, the mechanical design creates a sealed wind tunnel to bring in cold air and expels hot air via system fans to offer the system extreme stability and reliability.

Due to the vast variety of RTX 3050 graphics card on the market, we will focus on installation methods for PNY, MSI, and Sparkle RTX 3050 graphics cards. Below are the graphics card's details:

Brand	Model	Note
MSI	GeForce RTX™ 3050 AERO ITX 8GB OC	Global availability
PNY	GeForce RTX™ 3050 8GB XLR8 Gaming Single	US availability
	Fan Edition	
Sparkle	GeForce RTX 3050 8GB Graphics Card	Secured onto Cassette
		chassis directly


To install a graphics card into the Cassette module, please refer to the following procedure:

1. Turn the system upside-down and remove the four screws (indicated in **blue**) at the bottom of the Cassette module.




2. Gently wiggle and separate the Cassette module from the system.





3. Remove the screws to open the Cassette cover.


4. If you manage to acquire one of the three graphics cards mentioned above, please refer to the follow the instructions for preparations on installing into the Cassette module.





For MSI and PNY graphics cards, stick the two 36x6x6mm Poron-Cs onto the Cassette module cover


For PNY graphics card, stick the three 8 x8 x 6mm rubber cubes onto the back of the graphics card



For Sparkle graphics card, remove the two screws at the back of the graphics card (towards the end). Once the graphics card is installed into the Cassette module, these two screw holes will be used to secure the graphics card in place.


5. If you are replacing the existing graphics card, remove the screws holding the graphics card's I/O panel, unplug the 8-pin power cable, press the release notch at the back and gently lift the graphics card out of the PCIe slot.







Unplug the 8-pin power cable



Press the notch at the back to release the graphics card

6. If you are installing the graphics card for the first time, remove the bezel cover (indicated in blue circle) and insert the graphics card into the PCIe slot while making sure graphics card's bezel is properly inserted into the notch and the gold fingers are properly inserted.



Remove bezel cover



Make sure the card is inserted into the notch and PCIe slot


7. Secure the graphics card with screws and connect the 8-pin power cable.



Secure the graphics card

Connect the 8-pin power cable


8. If you are installing the Sparkle graphics card, use the M.2 screws provided in the accessory box, and secure the graphics card onto the Cassette module's enclosure.






9. Place the enclosure cover, and secure the enclosure with screws indicated.

10. Gently lower the Cassette module back onto the system enclosure and secure the module onto the system enclosure by securing the following screws.



3.4 Nuvo-9166GC Series Graphics Card Replacement/



Installation

The Cassette module compartmentalizes the heat generated and effectively manages thermal conditions of both the system and graphics card. The modular design reduces the complexity of installing and replacing graphics cards in the fanless controller. In addition, the mechanical design creates a sealed wind tunnel to bring in cold air and expels hot air via system fans to offer the system extreme stability and reliability.

To install L4 graphics card into the Cassette module, please refer to the following procedure:

1. Turn the system upside-down and remove the four screws (indicated in **blue**) at the bottom of the Cassette module.




2. Gently wiggle and separate the Cassette module from the system.



3. Remove the screws to open the Cassette cover.




4. If you are replacing the existing graphics card, remove the screws holding the graphics card's I/O panel and remove the three screws holding the duct.



Remove the screws securing the graphics card

Remove the three screws holding the dedicated tunnel duct

5. Make you remove the duct first before gently lifting the graphics card out of the PCIe slot.



Remove the duct



Gently lift the graphics card out of the PCIe slot

6. If you are installing the graphics card for the first time, remove one of the corresponding bezel cover (indicated in blue circle).



7. Insert and secure the graphics card into the PCIe slot while making sure graphics card's bezel is properly inserted into the notch and the gold fingers are properly inserted.






Insert and secure graphics card into PCIe slot

Bezel inserted into the notch



Properly inserted into the PCIe slot

8. Reinstall the duct to the end of the graphics card and secure it with screws.



Reinstall the duct

Secure with screws

9. Place the Cassette module cover back on and secure with screws.




10. Gently lower the Cassette module back onto the system enclosure and secure the module onto the system enclosure by securing the following screws.



3.5 Installing the System Enclosure

1. To reinstall the system enclosure, place the bottom panel on top of the motherboard while making sure both sides are inserted into the heatsink (indicated in **blue**).



2. Install the front panel and secure screws indicated in **blue**.




- 8 THE CAL CAL COMS 0 12 0 0 . 0 ۲ o O/I .OIZOW A+ CND IGN COMI COMB 0 00 0 0
- 3. Install the rear panel and secure screws indicated in **blue**.

4. Gently lower the Cassette module back onto the enclosure and secure it with screws (indicated in **blue**).



Install the Cassette module



Secure the screws indicated


3.6 Wall Mount Bracket Installation

You will need to remove the four (4) rubber stands at the bottom of the enclosure if they have been attached.

3.6.1 Wall Mount Bracket Installation


To install the system as a wall mount device, please refer to the following instructions.


 Take out the two wall mount brackets (indicated in blue) and four M4 screws out of the accessory box. Fix the wall mount brackets to the system enclosure using M4 screws (indicated in red).



2. Place the system on a flat surface portion of the wall and secure it with four (4) M4 screws.

3. When wall mounting, place the heatsink fins perpendicular to the ground for better heat dissipation efficiency.






3.6.2 Damping Bracket Installation (Optional)

NOTE

You will need to remove the four (4) rubber stands at the bottom of the enclosure and insert washers.

The optional patented anti-vibration damping bracket offers superior operating vibration resistance up to 1Grm with HDD or up to 5Grm with SSD. To install the bracket, please refer to the following installation procedure.

 Take out anti-vibration damping bracket (blue), eight M4 screws (red), eight anti-vibration grommets (purple), four washers, and eight sleeves (green) from the accessory box. Insert the M4 screws into the sleeves and through the anti-vibration grommets to secure the system to the bracket; and the bracket to a flat surface.



The damping bracket performs best when the system is installed horizontally.


3.7 Powering On the System

There are three methods to power on the system

- Pressing the power button
- Using an external non-latched switch by connecting to the remote on/ off plug
- Sending a LAN packet via Ethernet (Wake-on-LAN)

3.7.1 Powering On Using the Power Button


This is the simplest way to turn on your system. The power button on the front panel is a non-latched switch and behaves as the ATX-mode on/off control. With DC power connected, pushing the power button will turn on the system and the PWR LED indicator will light up. Pushing the button when system is on will turn off the system. If your operating system supports ATX power mode (i.e. Microsoft Windows or Linux), pushing the power button while the system is in operation will result in a pre-defined system behavior, such as shutdown or hibernation.



3.7.2 Powering On Using External Non-latched Switch

If your application demands the system to be placed inside a cabinet, you may use an external non-latched switch to power on/ off the system. The system provides a 3-pin "Remote On/ Off" plug for connecting a non-latched switch and acts as the ATX-mode power on/off control switch. The external non-latched switch acts exactly the same as the power button on the front panel. To setup and power on/ off the system using an external non-latched switch (ATX-mode), please follow the steps described below.


- 1. Acquire a non-latched switch with 3-pin plug.
- 2. Connect the non-latched switch to the Remote on/ off plug (Ctrl and GND pins).



3. With DC power connected, pushing the power button will turn on the system and the PWR LED indicator will light up. Pushing the button when system is on will turn off the system. If your operating system supports ATX power mode (i.e. Microsoft Windows or Linux), pushing the power button while the system is in operation will result in a pre-defined system behavior, such as shutdown or hibernation.

3.7.3 Powering On Using Wake-on-LAN

Wake-on-LAN (WOL) is a mechanism to wake up a computer system from a S5 (system off with standby power) state via issuing a magic packet. The system's Wake-on-LAN compatible GbE port is shown below.



NOTE

Please make sure the Intel® chipset and Ethernet driver has been properly installed prior to setting up WOL function.

To enable WOL function, please set up WOL settings in the BIOS and in the operating system by follow the steps described below.

- 1. When the system boots up, press F2 to enter BIOS setup utility.
- 2. Go to the [Power]>[Wake On LAN] and set it to [Enabled].
- Press F10 to "Save changes and exit BIOS" and allow the system boot into the operating system.
- Once booted into the Windows system, press "Windows key + E", right-click on

"Network>Properties>Change adapter settings". Locate and double-click on the adapter Intel® I219 Gigabit Network Connection, click on Configure...

Ethernet 1 Properties	Х
Networking Sharing	
Connect using:	
Intel(R) Ethemet Connection (2) I219-LM	
Configure	
This connection uses the following items:	
Client for Microsoft Networks	^
File and Printer Sharing for Microsoft Networks	
QoS Packet Scheduler	
Internet Protocol Version 4 (TCP/IPv4)	
Link-Layer Topology Discovery Mapper I/O Driver	
Microsoft Network Adapter Multiplexor Protocol	
 Microsoft LLDP Protocol Driver 	¥
< >	

5. Click on the **Power Management** tab and check the following options. Click on OK when done.

Intel(R) Ethernet Connection (2) I219-LM Properties				×	
Teaming	VLANs	Driver	Details	Events	
General	Link Speed	Advanced	Power N	lanagement	
(intel)	Power Saver and Wake on LAN Options				
Power Saver C	Options:				
Respond	to ARP requests	without waking :	system	~	
Respond	to NS requests w	ithout waking sy	stem		
	fficient Ethernet			~	
Wake on LAN					
	Magic Packet			^	
	Pattern Match		-		
Wake on	Magic Packet fro	om power off stat	e	~	
Respond to A	ARP requests with	out waking syst	em		
the system	Sets the adapter to respond to ARP requests without waking the system from sleep or hibernate. The system can remain in sleep or hibernate mode and still maintain its network presence.				
	OK Cancel				

Magic Packet

For example, NIC's 48-bit MAC Address is 78h D0h 04h 0Ah 0Bh 0Ch

DESTINATION SOURCE MISC

FF FFFFFFFFF

78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C

78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C

78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C

78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C

78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C

78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C

78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C

78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C

MISC CRC

There are some free tools available on Internet that can be used to send a magic packet. Please refer to the following link to understand more about <u>Magic Packet</u>.

4 System Configuration

4.1 BIOS Settings

The system is shipped with factory-default BIOS settings meticulously programmed for optimum performance and compatibility. In this section, we'll illustrate some of BIOS settings you may need to modify. Please always make sure you understand the effect of change before you proceed with any modification. If you are unsure of the function you are changing, it is recommended to change one setting at a time to see its effect(s).

Main Advanced Security Pow	wer Boot Exit	n on too oo cap o crincy	NOT OF
BIOS Version Build Date	NV9KD003. Buil 09/02/2022	d220902 s	This is the help for the hour, minute, second field. Valid range is from 0 to 23, 0 to 59, 0 to 59. INCREASE/REDUCE :
Processor Type	12th Gen Inte	I(R) Core(TM) i5-12400	H [_] .
System Memory Speed Total Memory DDR5 SODIMM SocketO	4800 MT/s 8192 MB 8192 MB		
Total Core Count: Number Of E-Core: Number Of P-Core:	6 Core(s) / O Core(s) / 6 Core(s) /	0 Thread(s)	
System Time System Date	[23:34:10] [01/01/2022]		
F1 Help Esc Exit	1/↓ Select Item +/→ Select Item	F5/F6 Change Values Enter Select ► SubHenu	F9 Setup Defaults F10 Save and Exit

NOTE

Not all BIOS settings will be discussed in this section. If a particular setting/ function you are after requires specific BIOS settings but is not discussed in this section, please contact Neousys Technical Support staff.

4.1.1 COM Port Configuration

The system's <u>COM1/ COM2</u> ports support RS-232 (full-duplex), RS-422 (full-duplex) and RS-485 (half-duplex) mode. You can set the COM1 operating mode via BIOS settings. Another option in BIOS called "*Slew Rate*" defines how sharp the rising/falling edge is for the output signal of COM1. For long-distance RS-422/485 transmission, you may set the "*Slew Rate*" option as "High" to improve signal quality. For RS-422/485 communication, the "*RS-422/485 Termination*" option determines whether to enable/disable internal termination of RS-422/485 transceiver according to your wiring configuration (e.g. with or without external termination).

Advanced			
Peripheral Configuration			Set COM1 as RS-232 (Full-Duplex), RS422 (Full-Duplex) or RS-485 (Half-Duplex).
COM1	<enabled></enabled>		
HS Mode	<disabled></disabled>		
Set COM1 as	<r\$-232></r\$-232>		
Slev Rate	<low></low>		
RS-422/485 Termination	<disabled></disabled>		
COM2	<enabled></enabled>		
HS Hode	<disabled></disabled>		
Set COM2 as	< <u>R</u> S=232>		
Slev Rate	<low></low>		
RS-422/485 Termination	<disabled></disabled>		
C0H3	<enabled></enabled>	Set COM1 as	
HS Mode	<disabled></disabled>	R\$-232	
COH4		R\$-422	
HS Mode		R\$-485	
C0M5	<enabled></enabled>		
HS Hode	<disabled></disabled>		
COM6	<disabled></disabled>		
HD Audio	<enabled></enabled>		
F1 Help	1/1 Select Item	F5/F6 Change Values	F9 Setup Defaults
Esc Exit	←/→ Select Item	Enter Select 🕨 SubMenu	F10 Save and Exit

To set COM port operating mode:

- 1. Press F2 when the system boots up to enter the BIOS setup utility.
- 2. Go to [Advanced] > [Peripheral Configuration].
- 3. Set the [Set COM1 Mode as] option to the desired mode.
- 4. Once set, press F10 to "Exit Saving Changes".

4.1.2 COM Port High Speed Mode

The high speed mode of each COM port effectively allows for the port's baud rate generator to operate at 8x the speed with an effective baud rate of 921,600 bps (115,200 x 8). Please refer to the following instructions on how to enable the high speed mode for your COM port (COM1 used as an example).


Advanced			
Peripheral Configuration			Enable/Disable high-speed mode for
			CON1. When enabled, input clock for
C0H1	<enabled></enabled>		baud rate generator is multiplied by 8.
HS Node	<disabled></disabled>		Consequently baud rate configured in
Set CON1 as	<rs-232></rs-232>		user's application will actually
Slew Rate	<low></low>		operate at 8x speed. This option allows
RS-422/485 Termination	<disabled></disabled>		a naximal baud rate of 921,600 bps (115,200 x 8) for CON1.
COM2	<enabled></enabled>		
HS Mode	<disabled></disabled>		
Set CON2 as	<r\$-232></r\$-232>		
Slev Rate	<low></low>		
RS-422/485 Termination	<disabled></disabled>		
СОМЗ	<enabled></enabled>		
HS Hode	<disabled></disabled>	HS Mode	
COM4	<enabled></enabled>	Disabled	
HS Hode	<disabled></disabled>	Enabled	
ino node	-51345154-		
C0H5	<enabled></enabled>		
HS Mode	<disabled></disabled>		
C0M6	<disabled></disabled>		
HD Audio	<enabled></enabled>		
F1 Help	1/1 Select Item	F5/F6 Change Values	F9 Setup Defaults
Esc Exit	←/→ Select Item	Enter Select SubMenu	F10 Save and Exit

To set COM port high speed mode:

- 1. Press **F2** when the system boots up to enter the BIOS setup utility.
- 2. Go to [Advanced] > [Peripheral Configuration].
- 3. Enable or set the [Set COM1 Mode as] option to the desired mode.
- 4. Highlight **[HS Mode]** and press ENTER to bring up options, highlight **[Enable]** and press ENTER.
- 5. Once set, press F10 to "Exit Saving Changes".

4.1.3 Delay for PEG Initialization

This setting offers delay in milliseconds for PEG port initialization and PCI enumeration. By increasing the delay value, it may eliminate compatibility issue(s) with some PCIe add-on cards.



To set PEG delay in milliseconds:

- 1. When system boots up, press F2 to enter BIOS setup utility.
- Go to [Advanced] > [System Agent (SA) Configuration] > [CPU PCI Express Configuration] > [Delay for PEG Init] and press ENTER.
- 3. A small window appears and you may enter a maximum delay value of up to 30,000ms.
- 4. When done, press F10 to "Exit Saving Changes"

4.1.4 Volume Management Device (VMD)

To set up a RAID 0 or 1 volume, you need to have at least two hard drives or SSDs installed. The system supports RAID configurations in RAID 0 (striping) or RAID 1 (mirror) mode. Users can select the configuration that best suit their needs with RAID 0 (striping) mode offering better hard drive read/ write performances while RAID 1 (mirror) offers better data security.


Please back up the hard drive data before you create or modify RAID volume(s) as the process may cause irreversible data deletion. When creating a RAID volume, it is also recommended to use hard drives from the same batch (same brand, model, capacity, rpm rate, etc.) to avoid performance or capacity allocation issues.

1. When system boots up, press F2 to enter BIOS setup utility.

Advanced		· ·	
Systen Agent (SA) Configuratio	n		VHD Configuration settings
VT-d	Supported		
 ▶Graphics Configuration ▶VHD setup menu ▶CPU PCT Express Configuration 			
VT-d GNA Device (E0:D8:F0) Above 468 MMIO BIOS assignment Max TOLUD	<enabled> <disabled> <enabled> <dynanic></dynanic></enabled></disabled></enabled>		
Fl Help Esc Exit	t/↓ Select litem +/+ Select litem	F5/F6 Change Values Enter Select ▶ SubMenu	F9 Setup Defaults F10 Save and Exit

2. Go to [Advanced] > [VMD setup menu], press ENTER.

3. Highlight **[Enable VMD controller]**, press ENTER to bring up Options, Enabled/ Disabled, select Enabled and press ENTER.



4. Highlight **[RAID0]** or **[RAID1]**, press ENTER to bring up options, Enabled/ Disabled, select your choice and press ENTER again to confirm selection.

Advanced		
VHD Configuration		Enable/Disable RAIDO support
Enable VMD controller	<enabled></enabled>	
Enable VHD Global Mapping Map this Root Port under VHD Root Port BDF details	<enabled> <disabled> SATA Controller</disabled></enabled>	
RA IDO RA IDI	<enabled> <enabled></enabled></enabled>	
Intel Rapid Recovery Technology RRT volumes can span internal and eSATA drives	<enabled> RAIDO Disabled Enabled</enabled>	
Fl Help 1/4 Selec Esc Exit +/+ Selec		Change Values F9 Setup Defaults Select ► Subhenu F10 Save and Exit

5. Highlight your selection, press Enter and press F10 to "Exit Saving Changes".

4.1.5 **TPM** Availability

Trusted Platform Module (TPM) is a hardware-based cryptoprocessor to secure hardware by integrating cryptographic keys into devices. The system is designed with on-board TPM 2.0 module. As TPM 2.0 requires 64-bit Windows 10 with UEFI boot mode, it is enabled in BIOS by default.

Main Advanced Security Power Boot	Exit	
Current TPM Device TPM State TPM Active PCR Hash Algorithm TPM Hardware Supported Hash Algorithm BlOS Supported Hash Algorithm TrEE Protocol Version TPM Availability TPM Operation Clear TPM	<tpm (dtpm)="" 2.0=""> All Hierarchies Enabled, Owned SHA256 SHA1, SHA256 SHA1, SHA256, SHA384, SHA512, SH3_256 <1.1> <available> <no operation=""> []</no></available></tpm>	When Hidden, don't exposes TPM to O
Supervisor Password	Not Installed	
Set Supervisor Password	TPH Availability Available Hidden	
F1 Help 1/4 Selec Esc Exit +/+ Selec		F9 Setup Defaults F10 Save and Exit

To enable TMP availability:

- 1. When system boots up, press F2 to enter BIOS setup utility.
- Go to [Security] > [TPM Availability], press ENTER to bring up Options, Available/ Hidden.
- 3. Highlight your selection, press Enter and press F10 to "Exit Saving Changes".

4.1.6 Power over Ethernet (PoE) Power Enable


Power over Ethernet (PoE) supplies electrical power and data on a standard CAT-5/CAT-6 Ethernet cable. Acting as a PoE PSE (Power Sourcing Equipment), compliant with IEEE 802.3at, each PoE port delivers up to 25W to a Powered Device (PD). The system has a total 100W power budget. The PoE power can be Enabled/ Disabled in the BIOS.

Main Advanced Security Pow	er Boot Exit		
▶CPU Configuration ▶Power & Performance			Enable/disable PoE power output.
PoE Pover Enable Lani PoE Lani PoE Lani PoE Lani PoE	<enabled> <enabled> <enabled> <enabled> <enabled></enabled></enabled></enabled></enabled></enabled>		
Wake on LAN Auto Wake on \$5	<d i="" led="" sab=""> <d i="" led="" sab=""></d></d>		
Power On after Power Failure	<s5 -="" power<="" th=""><th>r Off> PoE Power Enable Enabled Disabled</th><th></th></s5>	r Off> PoE Power Enable Enabled Disabled	
F1 Help Esc Exit	1/↓ Select Iten +/→ Select Iten	F5/F6 Change Values Enter Select ► SubMenu	F9 Setup Defaults F10 Save and Exit

To enable/ disable "PoE Power Enable" option:

- 1. When system boots up, press F2 to enter BIOS setup utility.
- 2. Go to [Power] > [PoE Power Enable].
- 3. Press ENTER to bring up setting options, scroll to the setting (Enabled/ Disabled) you desire and press ENTER to set.

4. You can also enable/ disable each port, individually. Simply use the arrow key to highlight the port, press ENTER to bring up options (Enabled/ Disabled), press ENTER again to select the option.



Nuvo-9160GC series LAN ports

Main Advanced Security Po	wer Boot Evit	in the second	
►CPU Configuration ►CPU Configuration			Enable/disable PoE power output for each LAN port.
PoE Power Enable LANT PoE LAN2 PoE LAN3 PoE LAN4 PoE	<enabled> <enabled> <enabled> <enabled> <enabled></enabled></enabled></enabled></enabled></enabled>		
Wake on LAN Auto Wake on \$5	<d i="" led="" sab=""> <d i="" led="" sab=""></d></d>		
Power On after Power Failure	<s5 -="" power<="" th=""><th>- Off> LAN2 POE Enabled Disabled</th><th></th></s5>	- Off> LAN2 POE Enabled Disabled	
Fl Help	1/1 Select Iten	F5/F6 Change Values	F9 Setup Defaults
Esc Exit	+/→ Select Iten	Enter Select 🕨 SubNenu	F10 \$ave and Exit

5. Press F10 to "Exit Saving Changes".

4.1.7 Auto Wake on S5

Auto Wake on S5

Disabled

By Every Day

By Day of Month

When the system is set to operate in S5 state, the user can specify a time to turn on the system, daily or monthly.

Main Advanced Security	Power Boot Exit	······		
▶CPU Configuration ▶Power & Performance			Auto wake on \$5. By Day of He Fixed time of every day	onth or
PoE Pover Enable LAN1 PoE LAN2 PoE LAN3 PoE LAN4 PoE	<enabled <enabled <enabled <enabled <enabled< td=""><td>></td><td></td><td></td></enabled<></enabled </enabled </enabled </enabled 	>		
Wake on LAN Auto Vake on S5	<disable <disable< td=""><td></td><td></td><td></td></disable<></disable 			
Power On after Power Failun	re <\$5 - Po	wer Auto Wake on S5 Disabled By Every Day By Day of Honth		
F1 Help Esc Exit	1/1 Select Ltem ←/+ Select Ltem	F5/F6 Change Values Enter Select ▶ SubMenu	F9 Setup Defaults F10 Save and Exit	
Value	Option	Description		

in state S5.

The system does not turn on when operating

operating in state S5. Specify the time of day.

The system turns on each day when


The system turns on each month when operating in state S5. Specify the day and

Highlight your selection	. press ENTER and	d press F10 to	"Exit Saving Changes".
	, p		

time.

4.1.8 Power On After Power Failure Option

This option defines the behavior of System series when DC power is supplied.




To set "Power On after Power Failure" option:

- 1. When system boots up, press F2 to enter BIOS setup utility.
- 2. Go to [Power] > [Power On after Power Failure].
- 3. Scroll down to highlight **[Power On after Power Failure]**, press ENTER to bring up setting options, S0 Power On or S5 Power Off, and press ENTER to select the setting.
- 4. Press F10 to "Exit Saving Changes".

4.1.9 Power & Performance (CPU SKU Power Configuration)

The system supports Intel 12th Gen Alder Lake LGA 1700 CPUs from 35W to 65W TDP. A unique feature, "**SKU Power Config**" is implemented in BIOS to allow users to specific user-defined SKU power limit. Although the system is designed to have best thermal performance with CPUs of 35W TDP, you can install a 65W CPU and limit its SKU power (to 35W) to obtain more computing power. This feature gives you the flexibility of CPU selection and great balance between computing power and operating temperature range.



To configure the CPU SKU power limit:

- 1. When the system boots up, press F2 to enter BIOS setup utility.
- 2. Go to [Power] \rightarrow [Power & Performance].
- 3. Select a proper value of SKU power limit for [SKU Power Config] option.
- 4. Press F10 to "Exit Saving Changes.

The option "Max. Boost" unleashes the CPU's maximum performance with the highest power consumption. Make sure you're using a power supply with a rated power output four times that of the CPU TDP to ensure reliable system operations.

4.1.10 Wake on LAN Option

Wake-on-LAN (WOL) is a mechanism which allows you to turn on your System series via the Ethernet connection. To utilize Wake-on-LAN function, you have to enable this option first in BIOS settings. Please refer "<u>Powering On Using Wake-on-LAN</u>" to set up the system.

Main Advanced Security Po	wer Boot Exit		
▶CPU Configuration ▶Power & Performance			Specify what state to go to when power is re-applied after a power failure (G3 state).
PoE Power Enable LAN1 PoE LAN2 PoE LAN3 PoE LAN4 PoE	<enabled> <enabled> <enabled> <enabled> <enabled></enabled></enabled></enabled></enabled></enabled>		
Wake on LAN Auto Wake on S5	<enabled> <disabled></disabled></enabled>		
Power On after Power Failure	<s5 (<="" -="" power="" th=""><th>Vff> Wake on LAN Disabled Enabled</th><th></th></s5>	Vff> Wake on LAN Disabled Enabled	
Fl Help Esc Exit	1/1 Select Iten €/+ Select Iten	F5/F6 Change Values Enter Select ► SubHenu	F9 Setup Defaults F10 Save and Exit

To enable/ disable "Wake on LAN" option:

- 1. When system boots up, press F2 to enter BIOS setup utility.
- 2. Go to [Power] > [Wake on LAN].
- 3. Press ENTER to bring up setting options, scroll to the setting you desire and press Enter to set.
- 4. Press F10 to "Exit Saving Changes".

4.1.11 Boot Menu

The Boot menu in BIOS allows you to specify the system's boot characteristics by setting bootable device components (boot media) and method. Or, you may press F12 upon system start up and select a device you wish boot from.

Harminood voodritty	Power Boot Exit		
Boot Type Quick Boot Quiet Boot Network Stack PXE Boot capability Add Boot Options ACPI Selection USB Boot Timeout Automatic Failover WDT for Booting	<uef1 bo<br=""><enabled <disabled <disabled <last> <acpi6.3 <enabled [3] <enabled <disabled< th=""><th>>>> d> d> d> >></th><th>Allows BIOS to skip certain tests w booting. This will decrease the tim needed to boot the system.</th></disabled<></enabled </enabled </acpi6.3 </last></disabled </disabled </enabled </uef1>	>>> d> d> d> >>	Allows BIOS to skip certain tests w booting. This will decrease the tim needed to boot the system.
F1 Help Esc Exit	1/↓ Select Item +/+ Select Item	F5/F6 Change Values Enter Select ▶ SubMenu	F9 Setup Defaults F10 Save and Exit
Value			
value	Option	Description	
Boot Type	Option UEFI Boot Type	Description Only UEFI boot media boot media.	listed are approved as
	-	Only UEFI boot media	ter because BIOS skips
Boot Type	UEFI Boot Type	Only UEFI boot media boot media. The system starts up fas various hardware functio The system starts up slo	ter because BIOS skips on tests wer because BIOS goes
Boot Type	UEFI Boot Type Enabled	Only UEFI boot media boot media. The system starts up fas various hardware functio The system starts up slo through various hardwar The system is available	ter because BIOS skips on tests wer because BIOS goes e functions tests
Boot Type Quick Boot	UEFI Boot Type Enabled Disabled	Only UEFI boot media boot media. The system starts up fas various hardware functio The system starts up slo through various hardwar	ter because BIOS skips on tests wer because BIOS goes e functions tests for network access
Boot Type Quick Boot Network Stack PXE Boot	UEFI Boot Type Enabled Disabled Enabled	Only UEFI boot media boot media. The system starts up fas various hardware functio The system starts up slo through various hardwar The system is available using UEFI. The system is not availa using UEFI. Only UEFI Network Stac	ter because BIOS skips on tests wer because BIOS goes e functions tests for network access ble for network access k is supported: Preboot
Boot Type Quick Boot Network Stack	UEFI Boot Type Enabled Disabled Enabled Disabled	Only UEFI boot media boot media. The system starts up fas various hardware functio The system starts up slo through various hardwar The system is available using UEFI. The system is not availa using UEFI.	ter because BIOS skips on tests wer because BIOS goes e functions tests for network access ble for network access k is supported: Preboot (PXE) is not supported

Add Boot Options	First	Newly detected boot media are placed at the top	
		of the boot order.	
	Last	Newly detected boot media are placed at the	
		bottom of the boot order.	
ACPI Selection	1.0B/ 3.0/ 4.0/	Advanced Configuration and Power Interface	
	5.0/ 6.0	allows the operating system to control system	
		power management	
USB Boot	Enabled	Allow boot from bootable USB devices.	
	Disabled	Does not allow boot from bootable USB devices	
Timeout	1, 2, 3, etc (in	Boot delay time in seconds to give the user time	
	seconds)	to activate the hotkey to access the BIOS	
Automatic	Enabled	Automatically checks for the next bootable	
Failover		device when the set default device fails.	
	Disabled	Will only boot from the designated device.	
WDT for booting	Disabled, 1, 3, 5,	WDT ensures a successful system boot by	
	10 (minutes)	specifying a timeout value	

4.1.12 Add Boot Options (Position New Boot Device)

The "Add Boot Options" allow you to determine whether a newly added device (eg. USB flash disk) is to boot as the first device to boot or the last in the boot sequence.

To set the newly-installed boot device as the first or last boot device:

- 1. Press **F2** when the system boots up to enter the BIOS setup utility.
- 2. Go to [Boot] > [Add Boot Options] menu.
- 3. Select [First] or [Last] for your newly-added boot device and press ENTER.

Main Advanced Security Powe	r Boot Exit		
Boot Type	<ueft boot<="" th=""><th>(ype></th><th>Position in Boot Order for Shell,Network and Removables</th></ueft>	(ype>	Position in Boot Order for Shell,Network and Removables
Quick Boot Quiet Boot Network Stack PXE Boot capability Add Boot Options ACPI Selection USB Boot Timeout Automatic Failover WDT for Booting	<enabled> <enabled> <disabled> <disabled> <last> <acpi6.3> <enabled> [3] <enabled> <oisabled></oisabled></enabled></enabled></acpi6.3></last></disabled></disabled></enabled></enabled>	Add Boot Options	
		First Last Auto	
	1/1 Select Item +/+ Select Item	F5/F6 Change Values Enter Select ▶ SubMenu	F9 Setup Defaults F10 Save and Exit

4. Once set, press **F10** to "Exit Saving Changes".

4.1.13 Watchdog Timer for Booting

The watchdog timer secures the boot process by means of a timer. Once the timer expires, a reset command is issued to initiate another booting process. There are two options in BIOS menu, "*Automatically after POST*" and "*Manually after Entering OS*". When "*Automatically after POST*" is selected, the BIOS automatically stops the watchdog timer after POST (Power-On Self Test) OK. When "*Manually after Entering OS*" is selected, the user must stop the watchdog timer once booted into the OS. This guarantees the system can always boot into the OS, otherwise another booting process will be initiated. For information about programming watchdog timer, please refer to <u>Watchdog Timer & Isolated DIO</u>.

Main Advanced Security Power	Boot Exit		
Boot Type Quick Boot	<uefi boot<br=""><enabled></enabled></uefi>	Туре>	Disable/Set watchdog timer for system booting. If the system can not boot up successfully within the given timer value, watchdog timer will reset the
Quiet Boot	<enabled></enabled>		system for anothing booting process.
Network Stack	<disabled></disabled>		
PXE Boot capability	<disabled> <last></last></disabled>		
Add Boot Options ACPI Selection	<last> <acp 3="" i6.=""></acp></last>		
USB Boot	<enabled></enabled>		
Timeout	[3]		
Automatic Failover	<enabled></enabled>		
WDT for Booting	<disabled></disabled>	YDT for Booting Disabled	
		1 Min. 3 Min. 5 Min. 10 Min.	
	/1 Select Item /+ Select Item	F5/F6 Change Values Enter Select ▶ SubMenu	F9 Setup Defaults F10 Save and Exit


To set the watchdog timer for boot in BIOS:

- 1. When system boots up, press F2 to enter BIOS setup utility.
- 2. Go to [Boot] menu.
- 3. Disable or select timeout value for [WDT for Booting] option.
- 4. Once you give a timeout value, the **[WDT Stop Option]** option appears. You can select *"Automatically after POST"* or *"Manually after Entering OS"*.
- 5. Press F10 to "Exit Saving Changes".


4.2 AMT Configuration

Intel® AMT (Active Management Technology) is a hardware-based technology for remotely managing target PCs via Ethernet connection. The system supports AMT function via its Ethernet port implemented with Intel I219-LM. Prior to using the AMT function to remotely control the system, you need to configure AMT password and network settings.

1. Connect Ethernet cable tol219-LM Ethernet port (indicated in blue).



2. When the system boots up, press F10 to enter the "Front Page" menu, use the arrow key to highlight MEBx and press ENTER.



3. When entering MEBx for the first time, it will ask for the default (old) password. Please type "admin" and press ENTER.



4. The system will then request that you enter a new password. The new password must consists of at least one 7-bit ASCII non alpha-numeric character, above 32 (eg,!, @, \$) and 8 to 32 characters long. Note that under score "_" is considered an alpha-numeric character.



 After typing your new password, it will bring you to the MEBx settings page. For more MEBx configuration details, please refer to <u>Intel® MEBX User Guide</u>.

	MEBx	
Intel(R) AMI Fintel(R) AMT Configuration Fintel(R) OEM Debug Configuration Change HE Password	<enabled></enabled>	
F10 \$ave and Exit F1 Help	Esc Exit 1/4 Select Iten	Enter Select ► SubMenu

4.3 RAID Configuration

To set up a RAID 0 or 1 volume, you need to have at least two hard drives or SSDs installed. The system supports RAID configurations in RAID 0 (striping) or RAID 1 (mirror) mode. Users can select the configuration that best suit their needs with RAID 0 (striping) mode offering better hard drive read/ write performances while RAID 1 (mirror) offers better data security.

Please back up the hard drive data before you create or modify RAID volume(s) as the process may cause irreversible data deletion. When creating a RAID volume, it is also recommended to use hard drives from the same batch (same brand, model, capacity, rpm rate, etc.) to avoid performance or capacity allocation issues.

4.3.1 Enabling Volume Management Device (VMD) for RAID Volume Setup

- 1. When system boots up, press F2 to enter BIOS setup utility.
- Go to [Advanced] > [System Agent (SA) Configuration] > [VMD setup menu], and press ENTER.

Advanced			
Systen Agent (SA) Configuratio	n		YMD Configuration settings
VT-d	Supported		
 Graphics Configuration VHD setup menu CPU PCI Express Configuration 	1		
VT-d GNA Device (B0:D8:F0) Above 468 MMIO BIOS assignment Max TOLUD	<enabled> <disabled> t <enabled> <dynamic></dynamic></enabled></disabled></enabled>		
F1 Help Esc Exit	1/1 Select Item +/+ Select Item	F5/F8 Change Values Enter Select ▶ SubMenu	F9 Setup Defaults F10 Save and Exit
ESLEXIL	Serect ritem	enter serect 💌 subnenu	FIU Save and EXIL

3. Select [Enable VMD controller] and press ENTER, highlight [Enabled] and press ENTER.

/MD Configuration		Enable/Disable to VMD controller
Enable VMD controller	<enabled></enabled>	
Enable VMD Global Mapping	<enabled></enabled>	
1ap this Root Port under VMD	<enabled></enabled>	
Root Port BDF details	SATA Controller	
RA IDO	<enabled></enabled>	
AID1	<enabled></enabled>	
RAID5	<enabled></enabled>	
AID10	<enabled></enabled>	
Intel Rapid Recovery Technology	<enabled></enabled>	
RT volumes can span internal and eSATA drives	<enabled></enabled>	
Intel(R) Optane(TM) Memory	<enabled controller<="" enable="" th="" vmd=""><th></th></enabled>	
	Disabled	
	Enabled	
1 Help 1/4 Select	t Item F5/F6 Change Values	F9 Setup Defaults


- 4. Press F10 to "Exit Saving Changes" and reboot the system.
- 5. When the system reboots, press [F3] to enter the Device Manager configuration utility.

4.3.2 RAID Volume Setup

1. Once you've press F3 upon system boot up and you are in the Device Manager configuration utility, select [Intel® Rapid Storage Technology] and press ENTER.

Device	: Hanager
Devices List ⊧Intel(R) Ropid Storage Technology	This formset allows the user to manage RAID volumes on the intel(R) RAID Controller
Press ESC to exit.	
F1 Help Esc Exit	t/i Select Hen Enter Select ▶ SubHenu

2. The following screen shows Non-RAID physical disks and the option "**Create RAID Volume**". Highlight "**Create RAID Volume**" and press ENTER to begin creating your RAID volume.



3. The Name option allows you to name your RAID volume. Press ENTER when ready to go to the next option.

Intel(R) Rapid Storage Technology			
Create RAID Volume			Enter a unique volume name that has no special characters and is 16 characters
Name: RAID Level:	Volume1 <raido (st<="" td=""><td></td><td>or less.</td></raido>		or less.
Select Disks: SATA 0.0, 2.5" SATA SSD 3HE3 CA12110160140038, 119.2GB SATA 0.1, 2.5" SATA SSD 3HE3 CA12110160140037, 119.2GB	< >		
Strip Size: Capacity (MB):	<64KB> [0]		
⊧Create Volume Select at least two disks		Name : Volume 1	
F1 Help Esc Exit	1/↓ Select Item +/→ Select Item	F5/F6 Change Values Enter Select ▶ SubMenu	F9 Setup Defaults F10 Save

4. The RAID Level option allows you to select RAID-0 (stripping) or RAID-1 (mirror) for your RAID volume. Press ENTER when ready.

Intel(R) Rapid Storage Technology Intel(R) Rapid Storage Technology			
Create RAID Volume		Si	elect RAID Level
Name: RAID Level:	Volume1 <raido (si<="" td=""><td>ripe)></td><td></td></raido>	ripe)>	
Select Disks: SATA 0.0, 2.5" SATA SSD 3ME3 CA12110160140038, 119.26B SATA 0.1, 2.5" SATA SSD 3ME3 CA12110160140037, 119.26B	< 5		
Strip Size: Capacity (MB):	<6 4KB> [0]		
⊧Create Volume Select at least two disks		RAID Level: RAIDO (Stripe) RAIDI (Hirror)	
F1 Help Esc Exit	1/1 Select Item +/+ Select Item	F5/F6 Change Values Enter Select ▶ SubMenu	F9 Setup Defaults F10 Save

5. The Select Disks option allows you to select disk drives for your RAID volume. Highlight a drive and press ENTER, use up/ down arrow keys to highlight "x" and press ENTER to confirm the selection. A minimum of two disk drives must be selected for RAID-0 or RAID-1 configuration. Press ENTER when ready.

		Rapid Storage Technology	
Intel(R) Rapid Storage Techno			
Create RAID Volume		x	- to Select Disk
Name: RAID Level:	Volume1 <raido (stri<="" td=""><td>pe)></td><td></td></raido>	pe)>	
Select Disks: SATA 0.0, 2.5" SATA SSD 3HE3 CA12110160140038, 119.2GB SATA 0.1, 2.5" SATA SSD 3HE3 CA12110160140037, 119.2GB	<>>		
Strip Size: Capacity (MB):	<16KB> [0]		
▶Create Volume Select at least two disks	SATA 0. 1, 2.5" SATA	SSD 3HE3 CA12110160140037, 119.20	28 28
F1 Help Esc Exit	1/1 Select Item +/→ Select Item	F5/F6 Change Values Enter Select ► SubMenu	F9 Setup Defaults F10 Save

6. The Stripe Size option allows you to configure the stripe size of your RAID volume. Available stripe sizes are 4KB, 8KB, 16KB, 32KB, 64KB, 128KB, use the up and down arrow keys to highlight and press ENTER to confirm the stripe size selection.

*RAID1(Mirror) does not offer Stripe Size options.

Intel(R) Rapid Storage Techn		Rapid Storage Technology	
Create RAID Volume		S	trip size help
Name: RAID Level:	Volume1 <raido (str<="" td=""><td>ipe)></td><td></td></raido>	ipe)>	
Select Disks: SATA 0.0, 2.5" SATA SSD 3HE3 CA12110160140038, 119.2GB SATA 0.1, 2.5" SATA SSD 3HE3 CA12110160140037, 119.2GB	<		
Strip Size: Capacity (HB): ▶Create Volume	< <u>64KB></u> [244204]	Strip Size: 4KB 8KB 16KB 32KB 64KB 128KB	
F1 Help Esc Exit	î/↓ Select Item +/→ Select Item	F5/F6 Change Values Enter Select ► SubMenu	F9 Setup Defaults F10 Save

 The Capacity (MB) option allows you to configure the storage capacity of your RAID volume. By default, the full storage capacity will be applied. Once you have entered a capacity, press ENTER to confirm.

Strip Size: Capacity (HB): ⊁Create Volume	<64₩> [976768]	
⊧Create Volume		976768 [Yes] [No]


The Create Volume option is the final step in the volume creation process. Highlight "Create Volume" and press ENTER to begin creating your RAID volume base on the settings you just configured.

	Intel(R) R	apid Storage Technology	
Intel(R) Rapid Storage Techn	ology		
Create RAID Volume			Create a volume with the settings specified above
Name:	Volume1		
RAID Level:	<raido (strip<="" th=""><th>e)></th><th></th></raido>	e)>	
Select Disks:			
SATA 0.0, 2.5" SATA SSD 3ME3	<x></x>		
CA12110160140038, 119.2GB SATA 0.1, 2.5" SATA SSD 3ME3	<x></x>		
CA12110160140037, 119.2GB	~~~		
Strip Size:	<64KB>		
Capacity (MB):	[244204]		
▶Create Volume			
F1 Help	↑/↓ Select Item	F5/F6 Change Values	F9 Setup Defaults
Esc Exit	+/→ Select Item	Enter Select 🕨 SubMenu	F10 Save

 A summary and status of the RAID volume will be shown when the RAID volume is successfully created.

	Intel(R)	Rapid Storage Technology		
Intel(R) Rapid Storage Technolo	99			
Intel(R) RST 19.0.0.5428 RST VM) Driver		Select to see more information the RAID Volume	about
RAID Yolumes: ⊁Volumel, RAIDO (Stripe), 238.50	18, Nornal			
	/↓ Select Item -/+ Select Item	F5/F6 Change Values Enter Select ▶ SubMenu	F9 Setup Defaults F10 Save	

10. Press F10 to save and Esc to exit the Intel® Rapid Storage Technology configuration page.



4.3.3 Loading RAID Driver for Windows Installation

To install Windows on the RAID volume you created, please refer to the following procedure:

- Please prepare a bootable Windows installation USB drive with the zip file "<u>f6vmdflpy-x64</u>". Download and unzip the driver files, copy the driver files onto the Windows installation USB drive.
- Connect the Windows installation USB drive into one of the USB connections on Nuvo-9000.
- 3. Windows installation process should automatically begin (if not, please make sure the boot device in BIOS is set properly).
- 4. Select the "Load Driver" icon.

Name		Total Size	Free Space Type
A Refresh	Delete	Eormat	- New
🕑 Load Driver	Extend		

5. In the pop-up Window, select "Browse", go to the directory where you saved the unzipped drivers "f6vmdflpy-x64", and click OK.

Selec	t the driver to install
	Load driver
	To install the device driver for your drive, insert the installation media containing the driver files, and then click OK. Note: The installation media can be a CD, DVD, or USB flash drive.
	Browse OK Cancel

Browse For Folder	×
Select the folder that contains drivers for your hardware.	
boot	<u>^</u>
efi	
f6vmdflpy-x64	
, sources	
	~
↓	Cancel

6. Select the driver "Intel RST VMD Controller 467F" and click on Next.

optrollor 4675 (C:\f6v	mdflav v64\iaStor\	(D inf)	
ontroller 467F (C:\f6v Ianaged Controller 09			
<i>3</i> 1	1999 - 20 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1 1999 -	288 - A.	

7. The previous created RAID volume shall appear as unallocated space.

Name		Total size	Free space	Туре
🛷 Drive 1 Una	illocated Space	223.6 GB	223.6 GB	

8. From here, just follow the standard Windows installation procedures.

5 OS Support and Driver Installation

5.1 Operating System Compatibility

The system supports most operating system developed for Intel® x86 architecture. The following list contains the operating systems which have been tested by Neousys Technology.

- Microsoft Window 10 LTSC 2021 (x64)
- Ubuntu 20.04.5 LTS, 22.04 LTS, 22.04.1 LTS or other distribution with kernel version ≥ 5.15 */**

🖗 NOTE

* For Linux system, user may need to manually compile and install the driver for Intel graphics or I225/ I226 GbE controller if the driver is not embedded in kernel. You can visit Intel website for further information.

** For distributions, graphics driver and RAID function may not be completely implemented in its kernel. You may encounter restrictions when using these features, such as triple independent display and RAID. For optimum operation, it is the users' responsibility to manually check for new drivers and upgrades!

Neousys may remove or update operating system compatibility without prior notice. Please contact us if your operating system of choice is not on the list.

5.2 System Driver Installation

The system drivers are available online, please click on this link to download the drivers.

5.3 Driver Installation for Watchdog Timer Control

Neousys provides a driver package which contain function APIs for Watchdog Timer control function. You should install the driver package (WDT_DIO_Setup.exe) in prior to use these functions. Please note that you must install WDT_DIO_Setup_v2.3.2.0 or later versions.

Please refer to this <u>link</u> to download WDT_DIO.

Appendix A Using WDT & DIO

The watchdog timer (WDT) function to ensure reliable system operation. The WDT is a hardware mechanism to reset the system if the watchdog timer is expired. Users can start the WDT and keeping resetting the timer to make sure the system or program is running. Otherwise, the system shall be reset.

In this section, we'll illustrate how to use the function library provided by Neousys to program the WDT functions. Currently, WDT driver library supports Windows 10 x64 and WOW64 platform. For other OS support, please contact Neousys Technology for further information.

Installing WDT_DIO Library


The WDT_DIO function library is delivered in the form of a setup package named **WDT_DIO_Setup.exe**. In prior to program WDT, you should execute the setup program and install the WDT library. Please use the following WDT_DIO_Setup packages according to your operating systems and application.

 For Windows 10 64-bit OS with 64-bit application (x64 mode), please install WDT_DIO_Setup_v2.3.2.0(x64).exe or later versions.

WDT and DIO Library Installation


To setup WDT & DIO Library, please follow instructions below.

1. Execute WDT_DIO_Setup.2.3.2.0.exe (or later) and the following dialog appears.



 Click "Next >" and specify the directory of installing related files. The default directory is C:Weousys\WDT_DIO.

 Once the installation has finished, a dialog will appear to prompt you to reboot the system. The WDT & DIO library will take effect after the system has rebooted.



4. When programming your WDT or DIO program, the related files are located in

Header File:	\Include
Library File:	\Lib
Function	\Manual
Reference:	
Sample Code:	\Sample\WDT_Demo (Demo for Watchdog Timer)

WDT Functions

InitWDT

	1
Syntax	BOOL InitWDT(void);
Description:	Initialize the WDT function. You should always invoke InitWDT() before set or start watchdog timer.
Parameter	None
Return Value	TRUE: Successfully initialized
	FALSE: Failed to initialize
Usage	BOOL bRet = InitWDT()

SetWDT

	1
Syntax	BOOL SetWDT(WORD tick, BYTE unit);
Description	
Description	Set timeout value and unit for watchdog timer. When InitWDT()
	is invoked, a default timeout value of 255 seconds is assigned.
Parameter	tick
	WORD value (1 ~ 65535) to indicate timeout ticks.
	unit
	BYTE value (0 or 1) to indicate unit of timeout ticks.
	0 : unit is minute
	1: unit is second
Return Value	If value of unit is correct (0 or 1), this function returns TRUE,
	otherwise FALSE.
Usage	WORD tick=255;
	BYTE unit=1; //unit is second.
	BOOL bRet = SetWDT(tick, unit); //timeout value is 255
	seconds

StartWDT

Syntax	BOOL StartWDT(void);
Description	Starts WDT countdown. Once started, the WDT LED indicator will begin blinking. If ResetWDT() or StopWDT is not invoked before WDT countdowns to 0, the WDT expires and the system resets.
Parameter	None
Return Value	If the timeout value is given in correct format (WDT started), this function returns TRUE, otherwise FALSE
Usage	BOOL bRet = StartWDT()

ResetWDT

Syntax	BOOL ResetWDT(void);
Description	Reset the timeout value to the value given by SetWDT().If
	ResetWDT() or StopWDT is not invoked before WDT
	countdowns to 0, the WDT expires and the system resets.
Parameter	None
Return Value	Always returns TRUE
Usage	BOOL bRet = ResetWDT()

StopWDT

Syntax	BOOL StopWDT(void);
Description	Stops the countdown of WDT. When WDT has stopped, the WDT LED indicator stops blinking.
Parameter	None
Return Value	Always returns TRUE
Usage	BOOL bRet = StopWDT()

Appendix B PoE On/ Off Control

The system offers 802.3at PoE+ ports and users are allowed to manually turn on or off the power supply of each PoE port. This can be useful in power device (PD) fault-recovery or power reset. The APIs are part of Neousys WDT_DIO driver package. Please follow the instructions in <u>Appendix AWatchdog Timer & Isolated DIO</u> for installation before programming PoE on/off control function.

GetStatusPoEPort

Syntax	BYTE GetStatusPoEPort (Byte port);
Description	Get current on/off status of designated PoE port.
Parameter	port
	BYTE value specifies the index of PoE port. Please refer to the
	following illustration, <i>port</i> should be a value of 1 ~ 4
Return Value	BYTE value indicating PoE on/off status
	0 if port is disabled (off)
	1 if port is enabled (on)
Usage	BYTE bEnabled = GetStatusPoEPort (1); //Get on/off status of PoE
	Port#1

PoE+ ports on the front panel

EnablePoEPort


Syntax	BOOL EnablePoEPort (BYTE port);
Description	Turn on PoE power of designated PoE port.
Parameter	port
	BYTE value specifies the index of PoE port. Please refer to the following illustration, <i>port</i> should be a value of $1 \sim 4$
Return Value	TRUE if enabled success
	FALSE if fail to enable.
Usage	BOOL bRet = EnablePoEPort (1); //Turn on PoE Port#1

C \bigcirc . IGN WDT HDD PWR Reset Ð 0 0 Q DVI DP 0 <u> (- = = =)</u> 00 3 \bigcirc - **D** 0 Ô + 4 Q VGA 0 0 \$\$C+ -0 -0 C 10 D C (++ 0 \bigcirc

PoE+ ports on the front panel

DisablePoEPort

Syntax	BOOL DisablePoEPort (BYTE port);
Description	Turn off PoE power of designated PoE port
Parameter	port
	BYTE value specifies the index of PoE port. Please refer to the following illustration, <i>port</i> should be a value of $1 \sim 4$
Return Value	TRUE if disabled success
	FALSE if fail to disable
Usage	BOOL bRet = DisablePoEPort (1); //Turn off PoE Port#1



PoE+ ports on the front panel