

Elmatic Sparrow NW10 Industrial Cellular VPN Router

Application Note 012

IPSec_Pre shared key with CISCO router

Version: V1.0.0
Date: Oct 2021
Status: Confidential



Directory

| 1. | Introduction | 3 |
|----|--------------------------|---|
| | 1.1 Overview | 3 |
| | 1.2 Compatibility | 3 |
| | 1.3 Version | 3 |
| | 1.4 Corrections | 3 |
| 2. | Topology | 4 |
| 3. | Configuration | 5 |
| | 3.1 Server Configuration | 5 |
| | 3.2 Client Configuration | 7 |
| 4. | Testing | 8 |

1. Introduction

1.1 Overview

This document contains information regarding the configuration and use of IPSec_Pre-shared key with CISCO router.

This guide has been written for use by technically competent personnel with a good understanding of the communications technologies used in the product, and of the requirements for their specific application.

1.2 Compatibility

This application note applies to:

Models Shown: Sparrow NW10 / Sparrow NW20

Firmware Version: V1.0.0 or newer Other Compatible Models: None

1.3 Version

Updates between document versions are cumulative. Therefore, the latest document will include all the content of previous versions.


| Release Date | Doc. Version | Firmware Version | Change Description |
|--------------|--------------|------------------|--------------------|
| 2021/08/30 | V1.0.0 | V1.0.0 | First released |
| | | | |

1.4 Corrections

Appreciate for corrections or rectifications to this application note, and if any request for new application notes please email to: elmark@elmark.com.pl



2. Topology



- 1. Sparrow runs as IPSec Client with any kind of IP, which can ping IPSec server IP successfully.
- 2. CISCO router runs as IPSec Server with a static public IP.
- 3. IPSec tunnel is established between Sparrow and cisco router.

3. Configuration

a) Server Configuration

```
1.Login to CISCO router and setting like below:
cisco2811#show running-config
Building configuration...
Current configuration: 3071 bytes
version 12.4
hostname cisco2811
logging message-counter syslog
enable secret 5 $1$tw/d$UQQ3Xh06n.2HHFeAVIgXJ.
no aaa new-model
ip domain name cisco.com
ip name-server 192.168.111.1
ip address-pool local
no ipv6 cef
multilink bundle-name authenticated
username cisco password 0 cisco
archive
log config
 hidekeys
crypto isakmp policy 10
encraes 256
hash md5
authentication pre-share
group 5
crypto isakmp key 6 cisco address 0.0.0.0 0.0.0.0
crypto ipsec transform-set NR500 esp-3des esp-md5-hmac
crypto dynamic-map DYN 10
set transform-set NR500
set pfs group5
match address 101
```


©2018 Elmark Automatyka www.elmark.com.pl




```
reverse-route
crypto map SMAP 10 ipsec-isakmp dynamic DYN
track 1 interface FastEthernet0/0 line-protocol
interface Loopback0
ip address 192.168.50.1 255.255.255.0
interface FastEthernet0/0
 ip address 192.168.111.254 255.255.255.0
 ip nat outside
 ip nat enable
 ip virtual-reassembly
 duplex full
 speed auto
 no mop enabled
crypto map SMAP
interface FastEthernet0/1
 ip address 192.168.5.1 255.255.255.0
ip nat inside
 ip nat enable
 ip virtual-reassembly
 duplex auto
speed auto
ip forward-protocol nd
ip route 0.0.0.0 0.0.0.0 192.168.111.1
no ip http server
no ip http secure-server
ip nat inside source list 10 interface FastEthernet0/0 overload
ip access-list extended VPN
permit ip 192.168.50.0 0.0.0.255 192.168.6.0 0.0.0.255
access-list 10 permit 192.168.5.0 0.0.0.255
access-list 101 permit ip 192.168.50.0 0.0.0.255 192.168.6.0 0.0.0.255
snmp-server community public RO
end
cisco2811#
```

3.2 Client Configuration

1. Go to **VPN>IPSec>IPSec>General Settings**, click the Edit Button and configure IPSec VPN as below picture. Click Save.



- 2. Click Save>Apply.
- 3.IPSec had been connected successfully. Go to **VPN>IPSec>Status** to check the connection status.






4. Testing

1. Ping from CISCO router to Sparrow, LAN to LAN communication is working correctly.

2. Ping from Sparrow to CISCO router, LAN to LAN communication is working correctly.



3. Test successfully.